## SCD4x

Breaking the size barrier in CO<sub>2</sub> sensing



#### Features

- Photoacoustic sensor technology PASens®
- Smallest form factor: 10.1 x 10.1 x 6.5 mm<sup>3</sup>
- Reflow solderable for cost effective assembly
- Large output range: 0 ppm 40'000 ppm
- Large supply voltage range: 2.4 5.5 V

- High accuracy: ±(40 ppm + 5 %)
- Digital I<sup>2</sup>C interface
- Integrated temperature and humidity sensor
- Low power operation down to < 0.4 mA avg.</li>
   @ 5 V, 1 meas. / 5 minutes

#### **Product Summary**

The SCD4x is Sensirion's next generation miniature CO<sub>2</sub> sensor. This sensor builds on the photoacoustic sensing principle and Sensirion's patented PAsens® and CMOSens® technology to offer high accuracy at an unmatched price and smallest form factor. SMD assembly allows cost- and space-effective integration of the sensor combined with maximal freedom of design. On-chip signal compensation is realized with the build-in SHT4x humidity and temperature sensor.

CO<sub>2</sub> is a key indicator for indoor air quality as high levels compromise humans' cognitive low power


and well-being. The SCD4x enables smart ventilation systems to regulate ventilation in the most energy-efficient and human-friendly way. Moreover, indoor air quality monitors and other connected devices based on the SCD4x can help maintaining low CO<sub>2</sub> concentration for a healthy, productive environment.

### **Device Overview**

Products	Details
SCD40-D-R2	Base accuracy, specified range 400 – 2'000 ppm
SCD41-D-R2	High accuracy, specified range 400 – 5'000 ppm, single shot mode supported

Full product list on page 21

### **Functional Block Diagram**



### Table of Contents

1	Sen	sor Performance	. 3
	1.1	CO <sub>2</sub> Sensing Performance	. 3
	1.2	Humidity Sensing Performance	. 3
	1.3	Temperature Sensing Performance <sup>5</sup>	. 3
2	Spe	cifications	. 4
	2.1	Electrical Specifications	. 4
	2.2	Absolute Maximum Ratings	. 4
	2.3	Interface Specifications	. 5
	2.4	Timing Specifications	. 6
	2.5	Material Contents	. 6
3	Digi	tal Interface Description	. 7
	3.1	Power-Up and Communication Start	. 7
	3.2	Data type & length	. 7
	3.3	Command Sequence Types	. 7
	3.4	SCD4x Command Overview	. 8
	3.5	Basic Commands	. 9
	3.6	On-Chip Output Signal Compensation	10
	3.7	Field Calibration	12
	3.8	Low Power operation	14
	3.9	Advanced Features	
	3.10	Low power single shot (SCD41)	17
	3.11	Checksum Calculation	
4	Mec	hanical specifications	19
	4.1	Package Outline	19
	4.2	Land Pattern	19
	4.3	Tape & Reel Package	20
	4.4	Moisture Sensitivity Level	20
	4.5	Soldering Instructions	21
	4.6	Traceability	21
5	Ord	ering Information	21
6	Rev	ision History	21

### 1 Sensor Performance

### 1.1 CO<sub>2</sub> Sensing Performance

Default conditions of 25 °C, 50 % RH, ambient pressure 1013 mbar, default periodic measurement and 3.3 V supply voltage apply to values in the table below, unless otherwise stated.

Parameter	Conditions	Value
CO <sub>2</sub> output range <sup>1</sup>	-	0 – 40'000 ppm
SCD40 CO <sub>2</sub> measurement accuracy <sup>2</sup>	400 ppm – 2'000 ppm	± (50 ppm + 5% of reading)
SCD41 CO <sub>2</sub> measurement accuracy <sup>2</sup>	400 ppm – 5'000 ppm	± (40 ppm + 5% of reading)
Repeatability	Typical	± 10 ppm
Response time <sup>3</sup>	т <sub>63%</sub> , typical	60 s
Accuracy drift per year with automatic self- calibration algorithm enabled <sup>4</sup>	Typical	± (5 ppm + 0.5 % of reading)

 Table 1: SCD40 and SCD41 CO2 sensor specifications

#### 1.2 Humidity Sensing Performance<sup>5</sup>

Parameter	Conditions	Value
Humidity measurement range	-	0 %RH – 100 %RH
	15 °C – 35 °C, 20 %RH – 65 %RH	± 6 % RH
Accuracy (typ.)	-10 °C – 60 °C, 0 %RH – 100 %RH	±9%RH
Repeatability	Typical	± 0.4 %RH
Response time <sup>3</sup>	т <sub>63%</sub> , typical	90 s
Accuracy drift	-	< 0.25 %RH / year

Table 2: SCD4x humidity sensor specifications

#### 1.3 Temperature Sensing Performance<sup>5</sup>

Parameter	Conditions	Value
Temperature measurement range	-	- 10°C – 60°C
Accuracy (typ.)	15 °C – 35 °C	± 0.8 °C
Accuracy (typ.)	-10 °C – 60 °C	± 1.5 °C
Repeatability	-	± 0.1°C
Response time <sup>3</sup>	т <sub>63%</sub> , typical	120 s
Accuracy drift	-	< 0.03 °C / year

Table 3: SCD4x temperature sensor specifications

<sup>&</sup>lt;sup>1</sup> Exposure to CO<sub>2</sub> concentrations smaller than 400 ppm can affect the accuracy of the sensor if the automatic self-calibration (ASC) is on.

<sup>&</sup>lt;sup>2</sup> Deviation to a high-precision reference. Accuracy is fulfilled by > 90% of the sensors after calibration. Rough handling, shipping and soldering reduces the accuracy of the sensor. Accuracy is restored with FRC or ASC recalibration features. Accuracy is based on tests with gas mixtures having a to lerance of ± 1.5%.

<sup>&</sup>lt;sup>3</sup> Time for achieving 63% of a respective step function when operating the SCD41 Evaluation Kit with default measurement mode. Response time depends on design-in, signal update rate and environment of the sensor in the final application.

<sup>&</sup>lt;sup>4</sup> For proper function of ASC field-calibration algorithm SCD4x has to be exposed to air with CO<sub>2</sub> concentration 400 ppm regularly. Maximum accuracy drift per year estimated from stress tests is ± (5 ppm + 2 % of reading). Higher drift values may occur if the sensor is not handled according to its handling instructions.

<sup>&</sup>lt;sup>5</sup> Design-in of the SCD4x in final application, self-heating of the sensor and the environment impacts the accuracy of the RH/T sensor. To realize indicated specifications, the temperature-offset of the SCD4x inside the customer device must be set correctly (see chapter 3.6). Best RH/T accuracy is realized when operating the SCD4x in low power periodic measurement mode.

#### **Specifications** 2

#### 2.1 **Electrical Specifications**

Parameter	Symbol	Conditions	Min.	Typical	Max.	Units
Supply voltage DC	Vdd		2.4	3.3 or 5.0	5.5	V
Voltage ripple peak to peak	VRPP				30	mV
Poak oupply ouront		V <sub>DD</sub> = 3.3 V		175	205	mA
Peak supply current <sup>6</sup>		$V_{DD} = 5 V$		115	137	mA
Average supply current for periodic	I	V <sub>DD</sub> = 3.3 V		15	18	mA
measurement, periodic measurement	IDD	V <sub>DD</sub> = 5 V		11	13	mA
Average supply current for periodic	1	V <sub>DD</sub> = 3.3 V		3.2	3.5	mA
measurement, low power periodic measurement	IDD	V <sub>DD</sub> = 5 V		2.8	3	mA
Average supply current for periodic single shot		V <sub>DD</sub> = 3.3 V		0.45	0.5	mA
measurement, 1 measurement / 5 minutes (SCD41 only) <sup>7</sup>	IDD	V <sub>DD</sub> = 5 V		0.36	0.4	mA
Input high level voltage	VIH		0.7 x V <sub>DD</sub>		1 x V <sub>DD</sub>	-
Input low level voltage	VIL				0.3 x V <sub>DD</sub>	-
Output low level voltage	Vol	3 mA sink current			0.66	V

Table 4 SCD4x electrical specifications

#### 2.2 Absolute Maximum Ratings

Stress levels beyond those listed in Table 5 may cause permanent damage to the device. Exposure to minimum/maximum rating conditions for extended periods may affect sensor performance and reliability of the device.

Parameter	Conditions	Value
Temperature operating conditions		-10-60°C
Humidity operating conditions <sup>8</sup>	Non-condensing	0 – 95 %RH
MSL Level		3
DC supply voltage		- 0.3 V - 6.0 V
Max voltage on pins SDA, SCL, GND		- 0.3 V to V <sub>DD</sub> +0.3 V
Input current on pins SDA, SCL, GND		- 280 mA to 100 mA
Short term storage temperature9		- 40°C – 70°C
Recommended storage temperature		10 °C – 50 °C
ESD HBM		2 kV
ESD CDM		500 V
Maintenance Interval	Maintenance free when ASC field- calibration algorithm <sup>10</sup> is used.	None
Sensor lifetime <sup>11</sup>	Typical operating conditions	> 10 years

Table 5: SCD4x operation conditions, lifetime and maximum ratings

<sup>&</sup>lt;sup>6</sup> Power supply should be designed with respect to peak current.

<sup>&</sup>lt;sup>7</sup> On-demand measurement with freely adjustable interval. See chapter 3.10

<sup>&</sup>lt;sup>8</sup> Accuracy can be reduced at relative humidity levels lower than 10 %.

 <sup>&</sup>lt;sup>9</sup> Short term storage refers to temporary conditions during e.g. transport.
 <sup>10</sup> For proper function of ASC field-calibration algorithm the SCD4x has to be exposed to clean air with 400 ppm CO<sub>2</sub> concentration regularly.

<sup>&</sup>lt;sup>11</sup> Sensor tested over simulated lifetime of > 10 years for indoor environment mission profile

#### 2.3 Interface Specifications

The SCD4x comes in an LGA package (**Table 6**). The package outline is schematically displayed in chapter 4.1. The landing pattern of the SCD4x can be found in chapter 4.2.





 Table 6 Pin assignment (top view). The notched corner of the protection membrane serves as a polarity mark to indicate pin 1 location.

VDD and VDDH are used to supply the sensor and must always be kept at the same voltage, i.e. should both be connected to the same power supply. The combined maximum current drawn on VDD and VDDH is indicated in **Table 4**. Care should be taken to choose a low noise power supply (preferably a low-dropout regulator, LDO, with output ripple of less than 30 mV p-p), which is adequately dimensioned for the relatively large peak currents. Power supply configurations with large transient voltage drops are to be avoided to ensure proper sensor operation.

SCL is used to synchronize the I<sup>2</sup>C communication between the master (microcontroller) and the slave (sensor). The SDA pin is used to transfer data to and from the sensor. For safe communication, the timing specifications defined in the I<sup>2</sup>C manual<sup>12</sup> must be met. Both SCL and SDA lines should be connected to external pull-up resistors (e.g.  $R_p = 10 \ k\Omega$ , see **Figure 1**). To avoid signal contention, the microcontroller must only drive SDA and SCL low. For dimensioning resistor sizes please take bus capacity and communication frequency into account (see example in Section 7.1 of NXPs I<sup>2</sup>C Manual for more details<sup>10</sup>). It should be noted that pull-up resistors may be included in I/O circuits of microcontrollers.



**Figure 1:** Typical application circuit (for better clarity in the image, the positioning of the pins does not reflect the positions on the real sensor). VDD and VDDH must be connected to each other close to the sensor on the customer PCB.

<sup>&</sup>lt;sup>12</sup> <u>http://www.nxp.com/documents/user\_manual/UM10204.pdf</u>

#### 2.4 Timing Specifications

**Table 7** list the timings of the ASIC part and does not reflect the availability or usefulness of the sensor readings. The SCD4x supports the I<sup>2</sup>C "standard-mode" as is described elsewhere (see footnote <sup>12</sup>).

Parameter	Condition	Min.	Max.	Unit
Power-up time	After hard reset, $V_{DD} \ge 2.25 V$	-	1000	ms
Soft reset time	After re-initialization (i.e. reinit)	-	1000	ms
SCL clock frequency	-	0	100	kHz

 Table 7 System timing specifications.

#### 2.5 Material Contents

The device is fully REACH and RoHS compliant.

### 3 Digital Interface Description

All SCD4x commands and data are mapped to a 16-bit address space.

SCD4x	Hex. Code
I <sup>2</sup> C address	0x62

Table 8 I<sup>2</sup>C device address.

#### 3.1 **Power-Up and Communication Start**

The sensor starts powering-up after reaching the power-up threshold voltage  $V_{DD,Min}$  = 2.25 V. After reaching this threshold voltage, the sensor needs 1000 ms to enter the idle state. Once the idle state is entered it is ready to receive commands from the master.


Each transmission sequence begins with a START condition (S) and ends with a STOP condition (P) as described in the I<sup>2</sup>Cbus specification.


#### 3.2 Data type & length

Data sent to and received from the sensor consists of a sequence of 16-bit commands and/or 16-bit words (each to be interpreted as unsigned integer, most significant byte transmitted first). Each data word is immediately succeeded by an 8-bit CRC. In write direction it is mandatory to transmit the checksum. In read direction it is up to the master to decide if it wants to process the checksum (see chapter 3.11).

#### 3.3 Command Sequence Types

The SCD4x features four different I<sup>2</sup>C command sequence types: "read I<sup>2</sup>C sequences", "write I<sup>2</sup>C sequences", "send I<sup>2</sup>C command" and "send command and fetch result" sequences. **Figure 2** illustrates how the I<sup>2</sup>C communication for the different sequence types is built-up.





For *"read"* or *"send command and fetch results"* sequences, after writing the address and/or data to the sensor and sending the ACK bit, the sensor needs the *execution time* (see **Table 9**) to respond to the I<sup>2</sup>C read header with an ACK bit. Hence, it is required to wait the command *execution time* before issuing the read header. Commands must not be sent while a previous command is being processed.

#### 3.4 SCD4x Command Overview

**Table 9**: List of SCD4x sensor commands. Detailed description of SCD4x commands can be found further down. \*Column indicates whether command can be executed while a periodic measurement is running.

Domain	Command	Hex.	I <sup>2</sup> C sequence type	Execution	
		Code	(see chapter 3.3)	time [ms]	During meas.*
	start_periodic_measurement	0x21b1	send command	-	no
Basic Commands Chapter 3.5	read_measurement	0xec05	read	1	yes
	stop_periodic_measurement	0x3f86	send command	time [ms]         -         1         500         10000         1200         20         5000	yes
	set_temperature_offset	0x241d	write	1	no
On-chip output signal	get_temperature_offset	0x2318	read	1	no
compensation	set_sensor_altitude	0x2427	write	1	no
Chapter 3.6	get_sensor_altitude	0x2322	read	1	no
	set_ambient_pressure	0xe000	write	1	yes
Field calibration	perform_forced_recalibration	0x362f	send command and fetch result	400	no
Chapter 3.7	set_automatic_self_calibration_enabled	0x2416	write	1	no
	get_automatic_self_calibration_enabled	0x2313	read	1	no
Low power	start_low_power_periodic_measurement	0x21ac	send command	-	no
Chapter 3.8	get_data_ready_status	0xe4b8	read	1	yes
	persist_settings	0x3615	send command	800	no
	get_serial_number	0x3682	read	1	no
Advanced features	perform_self_test	0x3639	read	10000	no
Chapter 3.9	perform_factory_reset	0x3632	send command	1200	no
	reinit	0x3646	send command	20	no
Low power single shot	measure_single_shot	0x219d	send command	5000	no
(SCD41 only) Chapter 3.10	measure_single_shot_rht_only	0x2196	send command	50	no

#### 3.5 Basic Commands

This section lists the basic SCD4x commands that are necessary to start a periodic measurement and subsequently read out the sensor outputs.

The typical communication sequence between the I<sup>2</sup>C master (e.g., a microcontroller) and the SCD4x sensor is as follows:

- 1. The sensor is powered up
- 2. The I<sup>2</sup>C master sends a *start\_periodic\_measurement* command. Signal update interval is 5 seconds.
- 3. The I<sup>2</sup>C master periodically reads out data with the read measurement sequence.
- 4. To put the sensor back to idle mode, the I<sup>2</sup>C master sends a *stop periodic measurement* command.

While a periodic measurement is running, no other commands must be issued with the exception of *read\_measurement*, *get\_data\_ready\_status*, *stop\_periodic\_measurement* and *set\_ambient\_pressure*.

#### 3.5.1 start\_periodic\_measurement

**Description**: start periodic measurement, signal update interval is 5 seconds.

 Table 10:
 start\_periodic\_measurement I<sup>2</sup>C sequence description

Write	Input parameter: -		Response parameter: -	Max. command				
(hexadecimal)	length [bytes]	signal conversion	length [bytes]	signal conversion	duration [ms]			
0x21b1	-	-	-	-	not applicable			
Example: start pe	Example: start periodic measurement							
Write	0x21b1							
(hexadecimal)	Command							

#### 3.5.2 read\_measurement

**Description**: read sensor output. The measurement data can only be read out once per signal update interval as the buffer is emptied upon read-out. If no data is available in the buffer, the sensor returns a NACK. To avoid a NACK response, the *get\_data\_ready\_status* can be issued to check data status (see chapter 3.8.2 for further details). The I<sup>2</sup>C master can abort the read transfer with a NACK followed by a STOP condition after any data byte if the user is not interested in subsequent data.

 Table 11: read\_measurment I<sup>2</sup>C sequence description

Write	Input parameter: -		· · · · ·	Response parameter: CO <sub>2</sub> , Temperature, Relative Humidity		
(hexadecimal)	length [bytes]	signal conve	ersion length	[bytes]	signal conversion	duration [ms]
			3		CO <sub>2</sub> [ppm] = word[0]	
0xec05	-	-	3		T = - 45 + 175 * word[1] / 2 <sup>16</sup>	1
		3		RH = 100 * word[2] / 2 <sup>16</sup>	1	
Example: read s	sensor output (500 p 0xec05	pm, 25 °C, 37 % RH	)			
(hexadecimal)	Command					
Wait	1 ms	command ex	ecution time			
Response	0x01f4	0x7b	0x6667	0xa2	0x5eb9	0x3c
(hexadecimal)	CO2 = 500 ppm	CRC of 0x01f4	Temp. = 25 °C	CRC of 0x66	667 RH = 37 %	CRC of 0x5eb9

#### 3.5.3 stop\_periodic\_measurement

**Description**: stop periodic measurement to change the sensor configuration or to save power. Note that the sensor will only respond to other commands after waiting 500 ms after issuing the *stop\_periodic\_measurement* command.

Table 12: stop\_periodic\_measurement I<sup>2</sup>C sequence description

Input parameter: -		Response parameter: -	Max. command	
length [bytes]	signal conversion	length [bytes]	signal conversion	duration [ms]
-	-	-	-	500
riodic measurement				
0x3f86				
Command				
	iength [bytes] - riodic measurement 0x3f86	length [bytes]     signal conversion       -     -       riodic measurement     0x3f86	length [bytes]     signal conversion     length [bytes]       -     -     -       riodic measurement     0x3f86	length [bytes]     signal conversion     length [bytes]     signal conversion       -     -     -     -       riodic measurement     0x3f86     -     -

#### 3.6 On-Chip Output Signal Compensation

The SCD4x features on-chip signal compensation to counteract pressure and temperature effects. Feeding the SCD4x with the pressure or altitude enables highest accuracy of the CO<sub>2</sub> output signal across a large pressure range. Setting the temperature offset improves the accuracy of the relative humidity and temperature output signal. Note that the temperature offset does not impact the accuracy of the CO<sub>2</sub> output.

To change or read sensor settings, the SCD4x must be in idle mode. A typical sequence between the I<sup>2</sup>C master and the SCD4x is described as follows:

- 1. If the sensor is operated in a periodic measurement mode, the I<sup>2</sup>C master sends a *stop\_periodic\_measurement* command.
- 2. The I<sup>2</sup>C master sends one or several commands to get or set the sensor settings.
- 3. If configurations shall be preserved after power-cycle events, the *persist\_settings* command must be sent (see chapter 3.9.1)
- 4. The I<sup>2</sup>C master sends a start measurement command to set the sensor in the operating mode again.

#### 3.6.1 set\_temperature\_offset

**Description**: The temperature offset has no influence on the SCD4x CO<sub>2</sub> accuracy. Setting the temperature offset of the SCD4x inside the customer device correctly allows the user to leverage the RH and T output signal. Note that the temperature offset can depend on various factors such as the SCD4x measurement mode, self-heating of close components, the ambient temperature and air flow. Thus, the SCD4x temperature offset should be determined inside the customer device under its typical operation conditions (including the operation mode to be used in the application) and in thermal equilibrium. Per default, the temperature offset is set to 4° C. To save the setting to the EEPROM, the *persist setting* (see chapter 3.9.1) command must be issued. Equation (1) shows how the characteristic temperature offset can be obtained.

$$T_{offset\_actual} = T_{SCD40} - T_{Reference} + T_{offset\_previous}$$
(1)

<b>Write</b> (hexadecimal)	Input parameter: Offset temperature			Response param	Max. command	
	length [bytes]	signal conversi	on	length [bytes]	signal conversion	duration [ms]
0x241d	3	word[0] = T <sub>offset</sub> [°C] * 2 <sup>16</sup> / 175		-	-	1
Example: set tem	perature offset to 5.4	4 °C				
Write	0x241d	0x07e6	0x48			
(hexadecimal)	Command	Toffset = 5.4 °C	CRC of 0x7e6			

 Table 13: set\_temperature\_offset I<sup>2</sup>C sequence description



#### 3.6.2 get\_temperature\_offset

<b>Write</b> (hexadecimal)	Input parameter: -	Input parameter: -		Response parameter: Offset temperature		
	length [bytes]	signal conversion	length [bytes]	signal conversion	command duration [ms]	
0x2318	-	-	3	T <sub>offset</sub> [°C] = 175 * word[0] / 2 <sup>16</sup>	1	
Example: tempe	erature offset is 6.2 °C					
Write	0x2318					
(hexadecimal)	Command					
Wait	1 ms	command execution tim	е			
Response	0x0912	0x63				
(hexadecimal)	Toffset = 6.2 °C	CRC of 0x0912				

Table 14: get\_temperature\_offset I2C sequence description

#### 3.6.3 set\_sensor\_altitude

**Description**: Reading and writing of the sensor altitude must be done while the SCD4x is in idle mode. Typically, the sensor altitude is set once after device installation. To save the setting to the EEPROM, the *persist setting* (see chapter 3.9.1) command must be issued. Per default, the sensor altitude is set to 0 meter above sea-level.

 Table 15: set\_sensor\_altitude I<sup>2</sup>C sequence description

<b>Write</b> (hexadecimal)	Input parameter: Sensor altitude		Response para	Response parameter: -						
	length [bytes]	signal conversion	length [bytes]	signal conversion	duration [ms]					
0x2427	3	word[0] = Sensor altitude [m]	-	-	1					
Example: set sens	Example: set sensor altitude to 1'950 m.a.s.l.									
Write	0x2427	0x079e 0x09								
(hexadecimal)	Command	Sensor altitude = 1'950 m	CRC of 0x79e							

#### 3.6.4 get\_sensor\_altitude

 Table 16: get\_sensor\_altitude I<sup>2</sup>C sequence description

Write (hexadecimal)	Input parameter: -		Response parar	Max. command					
	length [bytes]	signal conversion	length [bytes]	signal conversion	duration [ms]				
0x2322	-	-	3	Sensor altitude [m] = word[0]	1				
Example: sensor	Example: sensor altitude is 1'100 m.a.s.l.								
Write	0x2322								
(hexadecimal)	Command								
Wait	1 ms	command execution tim	е						
Response	0x044c	0x42							
(hexadecimal)	Sensor altitude = 1'100 m	CRC of 0x044c							

#### 3.6.5 set\_ambient\_pressure

**Description**: The *set\_ambient\_pressure* command can be sent during periodic measurements to enable continuous pressure compensation. Note that setting an ambient pressure using *set\_ambient\_pressure* overrides any pressure compensation based on a previously set sensor altitude.

Write (hexadecimal)	Input parameter	Input parameter: Ambient pressure		Response parameter: -		
	length [bytes]	signal conversion	length [bytes]	signal conversion	duration [ms]	
0xe000	3 word[0] = ambient P [Pa] / 100				1	
Example: set am	bient pressure to 98	'700 Pa				
Write	0xe000	0x03db	0x42			
(hexadecimal)	Command	Ambient P = 98'700 Pa	CRC of 0x03db			

Table 17: set\_ambient\_pressure I2C sequence description

#### 3.7 Field Calibration

To realize high initial and long-term accuracy, the SCD4x includes two field calibration features. Forced recalibration (FRC) enables restoring highest accuracy with the assistance of a CO<sub>2</sub> reference value immediately. Typically, FRC is applied to compensate for drifts originating from the sensor assembly process or other extensive stresses. Automatic self-calibration (ASC) ensures highest long-term stability of the SCD4x without the need of manual action steps from the user. The automatic self-calibration algorithm assumes that the sensor is exposed to the atmospheric CO<sub>2</sub> concentration of 400 ppm at least once per week.

#### 3.7.1 perform\_forced\_recalibration

**Description**: To successfully conduct an accurate forced recalibration, the following steps need to be carried out:

- 1. Operate the SCD4x in the operation mode later used in normal sensor operation (*periodic measurement, low power periodic measurement* or *single shot*) for > 3 minutes in an environment with homogenous and constant CO<sub>2</sub> concentration.
- 2. Issue stop\_periodic\_measurement. Wait 500 ms for the stop command to complete.
- 3. Subsequently issue the *perform\_forced\_recalibration* command and optionally read out the FRC correction (i.e. the magnitude of the correction) after waiting for 400 ms for the command to complete.
  - A return value of 0xffff indicates that the forced recalibration has failed.

Note that the sensor will fail to perform a forced recalibration if it was not operated before sending the command. Please make sure that the sensor is operated at the voltage desired for the application when applying the forced recalibration sequence.

#### Table 18: perform\_forced\_recalibration I<sup>2</sup>C sequence description

Write (hexadecimal)	Input parameter: Ta	rget CO <sub>2</sub> concentration	Response param	Response parameter: FRC-correction		
	length [bytes]	signal conversion	length [bytes]	signal conversion	command duration [ms]	
0x362f	3	word[0] = Target concentration [ppm CO <sub>2</sub> ]	3	FRC correction [ppm CO <sub>2</sub> ] = word[0] – 0x8000	400	
				word[0] = 0xffff in case of failed FRC		
Example: perfor	m forced recalibration, re	eference CO <sub>2</sub> concentration is	490 ppm	-		
Write	0x362f	0x01e0	0xb4			
(hexadecimal)	Command	Input: 480 ppm	CRC of 0x01e0			
Wait	400 ms	command execution time				
Response	0x7fce	0x7b				
(hexadecimal)	Response: - 50 ppm	CRC of 0x7fce				

#### 3.7.2 set\_automatic\_self\_calibration\_enabled

**Description**: Set the current state (enabled / disabled) of the automatic self-calibration. By default, ASC is enabled. To save the setting to the EEPROM, the *persist\_setting* (see chapter 3.9.1) command must be issued.

 Table 19: set\_automatic\_self\_calibration\_enabled I<sup>2</sup>C sequence description.

<b>Write</b> (hexadecimal)	Input parameter: ASC enabled			Response para	Max. command				
	length [bytes]	signal conversion	on	length [bytes]	signal conversion	duration [ms]			
0x2416	3	word[0] = 1 $\rightarrow$ ASC enabled word[0] = 0 $\rightarrow$ ASC disabled		-	-	1			
Example: set auto	Example: set automatic self-calibration status: enabled								
Write	0x2416	0x0001	0xB0						
(hexadecimal)	Command	ASC enabled	CRC of 0x0001						

#### 3.7.3 get\_automatic\_self\_calibration\_enabled

 Table 20: get\_automatic\_self\_calibration\_enabled I<sup>2</sup>C sequence description

<b>Write</b> (hexadecimal)	Input parameter: -	Input parameter: -		Response parameter: ASC enabled		
	length [bytes]	signal conversion	length [bytes]	signal conversion	duration [ms]	
0x2313	-	-	3	word[0] = 1 $\rightarrow$ ASC enabled word[0] = 0 $\rightarrow$ ASC disabled	1	
Example: read a	automatic self-calibratic	on status: disabled				
Write	0x2313					
(hexadecimal)	Command					
Wait	1 ms	command execution tir	ne			
Response	0x0000	0x81				
(hexadecimal)	ASC disabled	CRC of 0x0000				

#### 3.8 Low Power operation

To enable use-cases with a constrained power-budget, the SCD4x features a low power periodic measurement mode with signal update interval of approximately 30 seconds. While the low power mode saves power and reduces self-heating of the sensor, the low power periodic measurement mode has a longer response time.

The low power periodic measurement mode is initiated and read-out in a similar manner as the default periodic measurement. Please consult chapter 3.5.2 for further instructions. To avoid receiving a NACK in case the result of a subsequent measurement is not ready yet, the *get\_data\_ready\_status* command can be used to check whether new measurement data is available for read-out.

#### 3.8.1 start\_low\_power\_periodic\_measurement

Description: start low power periodic measurement, signal update interval is approximately 30 seconds.

 Table 21:
 start\_low\_power\_periodic\_measurement I<sup>2</sup>C sequence description

Write (hexadecimal)	Input parameter: -		Response paramet	Max. command	
	length [bytes]	signal conversion	length [bytes]	signal conversion	duration [ms]
0x21ac	-	-	-	-	not applicable
Example: start lov	w power periodic mea	surement			
Write	0x21ac				
(hexadecimal)	Command				

#### 3.8.2 get\_data\_ready\_status

 Table 22:
 get\_data\_ready\_status
 I<sup>2</sup>C sequence description

Write	Input parameter: -		Response pa	Max. command	
(hexadecimal)	length [bytes]	signal conversion	length [bytes]	signal conversion	duration [ms]
0xe4b8	-	-	3	If the least significant 11 bits of word[0] are $0 \rightarrow data not ready$	1
				else $\rightarrow$ data ready for read-out	
Example: read da	ta ready status: data no	t ready			
Write	0xe4b8				
(hexadecimal)	Command				
Wait	1 ms	command execution time	9		
Response	0x8000		0xa2		
(hexadecimal)	Least significant 11 bits	are 0 $\rightarrow$ data not ready	CRC of 0x8000		



#### 3.9 Advanced Features

#### 3.9.1 persist\_settings

**Description**: Configuration settings such as the temperature offset, sensor altitude and the ASC enabled/disabled parameter are by default stored in the volatile memory (RAM) only and will be lost after a power-cycle. The *persist\_settings* command stores the current configuration in the EEPROM of the SCD4x, making them persistent across power-cycling. To avoid unnecessary wear of the EEPROM, the *persist\_settings* command should only be sent when persistence is required and if actual changes to the configuration have been made. The EEPROM is guaranteed to endure at least 2000 write cycles before failure. Note that field calibration history (i.e. FRC and ASC, see chapter 3.7) is automatically stored in a separate EEPROM dimensioned for the specified sensor lifetime.

 Table 23: persist\_settings I<sup>2</sup>C sequence description

<b>Write</b> (hexadecimal)	Input parameter: -		Response parameter:	Max. command	
	length [bytes]	signal conversion	length [bytes]	signal conversion	duration [ms]
0x3615	-	-	-	-	800
Example: persist	settings				
Write	0x3615				
(hexadecimal)	Command				

#### 3.9.2 get\_serial\_number

**Description**: Reading out the serial number can be used to identify the chip and to verify the presence of the sensor. The get serial number command returns 3 words, and every word is followed by an 8-bit CRC checksum. Together, the 3 words constitute a unique serial number with a length of 48 bits (big endian format).

 Table 24: get\_serial\_number I<sup>2</sup>C sequence description

Write	Input paramete	Input parameter: -		Response parame	Max. command	
(hexadecimal)	length [bytes]	signal conv	ersion	ength [bytes]	signal conversion	duration [ms]
0x3682	-	-	g	9 Serial number = word[0] << 32   word[1] << 16   word[2]		1
Example: serial	number is 273'325'	796'834'238				
Write	0x3682					
(hexadecimal)	Command					
Wait	1 ms	command ex	ecution time			
Response	0xf896	0x31	0x9f07	0xc2	0x3bbe	0x89
(hexadecimal)	word[0]	CRC of 0xf896	word[1]	CRC of 0x	(9f07 word[2]	CRC of 0x3bbe

#### 3.9.3 perform\_self\_test

**Description**: The perform\_self\_test feature can be used as an end-of-line test to check sensor functionality and the customer power supply to the sensor.

Table 25: perform\_self\_test I<sup>2</sup>C sequence description

Write	Input parameter: -		Response paran	Max. command		
(hexadecimal)	length [bytes]	signal conversion	length [bytes]	signal conversion	duration [ms]	
0x3639	-	-	3	word[0] = 0 $\rightarrow$ no malfunction detected word[0] $\neq$ 0 $\rightarrow$ malfunction detected	10000	
Example: perform	Example: perform self-test, no malfunction detected					
Write	0x3639					
(hexadecimal)	Command					
Wait	10000 ms command execution time					
Response	0x0000	0x81				
(hexadecimal)	No malfunction de	etected CRC of	of 0x0000			

#### 3.9.4 perfom\_factory\_reset

**Description**: The perform\_factory\_reset command resets all configuration settings stored in the EEPROM and erases the FRC and ASC algorithm history.

Table 26: perform\_factory\_reset I<sup>2</sup>C sequence description

Input parameter: -		Response parameter: -	Max. command		
length [bytes]	signal conversion	length [bytes]	signal conversion	duration [ms]	
-	-	-	-	1200	
Example: perform factory reset					
0x3632					
Command					
	length [bytes] - actory reset 0x3632	length [bytes]     signal conversion       -     -       actory reset     0x3632	length [bytes]     signal conversion     length [bytes]       -     -     -       actory reset     0x3632	length [bytes]     signal conversion     length [bytes]     signal conversion       -     -     -     -       actory reset     0x3632     -     -	

#### 3.9.5 reinit

**Description**: The reinit command reinitializes the sensor by reloading user settings from EEPROM. Before sending the reinit command, the stop measurement command must be issued. If the *reinit* command does not trigger the desired re-initialization, a power-cycle should be applied to the SCD4x.

 Table 27: reinit I<sup>2</sup>C sequence description

Write	Input parameter: -		Response parameter: -	Max. command	
(hexadecimal)	length [bytes]	signal conversion	length [bytes]	signal conversion	duration [ms]
0x3646	-	-	-	-	20
Example: reinit					
Write	0x3646				
(hexadecimal)	Command re-initialization				

#### 3.10 Low power single shot (SCD41)

In addition to periodic measurement modes, the SCD41 features a single shot measurement mode, i.e. allows for on-demand measurements.

The typical communication sequence is as follows:

- 1. The sensor is powered up.
- 2. The I<sup>2</sup>C master sends a single shot command and waits for the indicated max. command duration time.
- 3. The I<sup>2</sup>C master reads out data with the *read measurement* sequence (chapter 3.5.2).
- 4. Steps 2-3 are repeated as required by the application.

To reduce noise levels, the I<sup>2</sup>C master can perform several single shot measurements in a row and average the CO<sub>2</sub> output values. After a power cycle, the initial two single shot readings should be discarded to maximize accuracy. The idle current in between measurements is 0.15 mA (typ.), respectively 0.2 mA (max.). The energy consumed per single shot typically is 243 mJ (296 mJ max.).

As for the periodic measurement modes, the automatic self-calibration (ASC) is enabled per default in single shot operation. The automatic self-calibration is optimized for single shot measurements performed every 5 minutes. Longer measurement intervals will result in less frequent self-calibration sequences. Note that no self-calibration is issued if the sensor is power-cycled between single shot measurements Please consult Chapter 3.7 for a detailed description of the automatic-self calibration and the corresponding commands.

#### 3.10.1 measure\_single\_shot

**Description**: On-demand measurement of CO<sub>2</sub> concentration, relative humidity and temperature. The sensor output is read using the *read\_measurement* command (chapter 3.5.2).

Write	Input parameter: -		Response parameter: -	Max. command		
(hexadecimal)	length [bytes]	signal conversion	length [bytes]	signal conversion	duration [ms]	
0x219d	-	-	-	-	5000	
Example: measur	Example: measure single shot					
Write	0x219d					
(hexadecimal)	Command					

 Table 28: measure\_single\_shot I<sup>2</sup>C sequence description

#### 3.10.2 measure\_single\_shot\_rht\_only

**Description**: On-demand measurement of relative humidity and temperature only. The sensor output is read using the *read\_measurement* command (chapter 3.5.2). CO<sub>2</sub> output is returned as 0 ppm.

Table 29: measure\_single\_shot\_rht\_only I<sup>2</sup>C sequence description

Write (hexadecimal)	Input parameter: -		Response parameter:	Response parameter: -		
	length [bytes]	signal conversion	length [bytes]	signal conversion	duration [ms]	
0x2196	-	-	-	-	50	
Example: measure single shot, RH and T output only						
Write	0x2196					
(hexadecimal)	Command					

#### 3.11 Checksum Calculation

The 8-bit CRC checksum transmitted after each data word is generated by a CRC algorithm. Its properties are displayed in **Table 30**. The CRC covers the contents of the two previously transmitted data bytes. To calculate the checksum only these two previously transmitted data bytes are used. Note that command words are not followed by CRC.

Property	Value	Example code (C/C++)
Name	CRC-8	#define CRC8_POLYNOMIAL 0x31
Width	8 bit	#define CRC8_INIT 0xFF
Protected Data	read and/or write data	uint8_t sensirion_common_generate_crc(const uint8_t* data, uint16_t count) {
Polynomial	0x31 (x8 + x5 + x4 + 1)	<pre>uint16_t current_byte; uint8_t crc = CRC8_INIT;</pre>
Initialization	0xFF	uint8_t crc_bit; /* calculates 8-Bit checksum with given polynomial */
Reflect input	False	<pre>for (current_byte = 0; current_byte &lt; count; ++current_byte) {</pre>
Reflect output	False	crc ^= (data[current_byte]); for (crc bit = 8; crc bit > 0;crc bit) {
Final XOR	0x00	if (crc & 0x80)
Examples	CRC (0xBEEF) = 0x92	<pre>crc = (crc &lt;&lt; 1) ^ CRC8_POLYNOMIAL;</pre>

 Table 30 I<sup>2</sup>C CRC properties.

### 4 Mechanical specifications

#### 4.1 Package Outline

Figure 3 schematically displays the package outline. The notched corner of the protection membrane serves as a polarity mark to indicate pin 1 location. Nominal dimensions and tolerances are listed in Table 31.




Figure 3: Packaging outline drawing of the SCD4x: (left) top view and (right) side view. Nominal dimensions and tolerances are listed in millimeters.

Dimension	а	b	C	d	е	f
Nominal [mm]	10.1	10.1	8.5	7.8	5.5	0.8
Tolerance [mm]	±0.3	±0.3	±0.2	±0.2	± 0.3	± 0.2

**Table 31**: Nominal dimensions and tolerances SCD4x (all in mm). The weight of the sensor is approx.0.6 g.

Note that the white protection membrane on top of the sensor must not be removed or tampered with to ensure proper sensor operation.

#### 4.2 Land Pattern

Recommended land pattern, solder paste and solder mask are shown in **Figure 4**. These are recommendations only and not specifications. The exact mask geometries, distances and stencil thicknesses must be adapted to the customer soldering processes.





Figure 4: SCD4x footprint (top view): landing pads (a), solder mask (b) and solder paste (c).

#### 4.3 Tape & Reel Package



**Figure 5**: Technical drawing of the packaging tape with sensor orientation in tape. Header tape is to the right and trailer tape to the left on this drawing. Dimensions are given in millimeters.

#### 4.4 Moisture Sensitivity Level

Sensirion SCD4x sensors shall be treated according to Moisture Sensitivity Level 3 (MSL3) as described in IPC/JEDEC J-STD-033B1. Exposure to moisture levels or solder reflow temperatures, which exceed the limits as stated in this document, can result in yield loss and reliability degradation.

The manufacturing floor time (out of bag) at the customer's end is 168 hours at normal factory conditions ( $\leq$ 30°C and 60%RH). If sensors are not mounted within this time, or have been exposed to higher temperatures and humidity (>30°C and >60%RH), or there is any doubt about the airtight integrity of the dry pack, the parts should be baked (baking parameters see **Table 32**). The maximum allowed baking temperature is 40°C if the sensors are inside the reel.

 Table 32: Baking condition SCD4x if floor time (168 h) with open bag is exceeded.

SCD4x package type	Baking temperature	Min. baking time	Baking condition
Sensors removed from tape	90 °C	48 hours	RH < 5 %
Sensors in tape	40 °C	23 days	RH < 5 %

#### 4.5 Soldering Instructions

For soldering, standard reflow soldering ovens may be used. The sensors are designed to withstand soldering profile according to IPC/JEDEC J-STD-020 with a maximum peak temperature of 235 °C during up to 30 sec for Pb-free assembly in IR/Convection reflow ovens.

Note that due to the comparably large size of the SCD4x sensor significant temperature differences across the sensor element can occur during reflow soldering. Specifically, the temperature within the sensor cap can be higher than the temperature measured at the pad using usual temperature monitoring methods. Care must be taken that a temperature of 235° C is not exceeded at any time in any part of the sensor.

Do not apply any board wash process step subsequently to the reflow soldering. Note that the dust cover on top of the cap must not be removed or wetted with any liquid. Finally, the SCD4x is not compatible with vapor phase reflow soldering.




 Table 33 Soldering profile parameter

#### 4.6 Traceability

All SCD4x sensors have a distinct electronic serial number for identification and traceability (see chapter 3.9.2). The serial number can be decoded by Sensirion only and allows for tracking through production, calibration, and testing.

### 5 Ordering Information

Use the part names and product numbers shown in the following table when ordering the SCD4x CO<sub>2</sub> sensor. For the latest product information and local distributors, visit <u>http://www.sensirion.com/</u>.

Part Name	Description	Ordering quantity (pcs)	Product Number
SCD40-D-R2	SCD40 CO2 sensor SMD component as reel, I2C	600 sensors per reel	3.000.521
SCD40-D-R1	SCD40 CO2 sensor SMD component as reel, I2C	60 sensors per reel	3.000.496
SCD41-D-R2	SCD41 CO2 sensor SMD component as reel, I2C	600 sensors per reel	3.000.498
SCD41-D-R1	SCD41 CO2 sensor SMD component as reel, I2C	60 sensors per reel	3.000.497
SEK-SCD41-Sensor	SEK-SCD41-Sensor set; SCD41 on development board with cables	1	3.000.455
SEK-SensorBridge	Sensor Bridge to connect SEK-SCD41-Sensor to computer	1	3.000.124

Table 34 SCD4x ordering options

#### 6 Revision History

Date	Version	Page(s)	Changes
January 2021	1	all	Initial release
April 2021	1.1	16 - 17	Adjustment max. command time self-test (chapter 3.9) and single shot (chapter 3.10), minor revisions on other pages

### **Important Notices**

#### Warning, Personal Injury

Do not use this product as safety or emergency stop devices or in any other application where failure of the product could result in personal injury. Do not use this product for applications other than its intended and authorized use. Before installing, hand ling, using or servicing this product, please consult the data sheet and application notes. Failure to comply with these instructions could result in death or serious injury.

If the Buyer shall purchase or use SENSIRION products for any unintended or unauthorized application, Buyer shall defend, indemnify and hold harmless SENSIRION and its officers, employees, subsidiaries, affiliates and distributors against all claims, costs, damages and expenses, and reasonable attorney fees arising out of, directly or indirectly, any claim of personal injury or death associated with such unintended or unauthorized use, even if SENSIRION shall be allegedly negligent with respect to the design or the manufacture of the product.

#### **ESD** Precautions

The inherent design of this component causes it to be sensitive to electrostatic discharge (ESD). To prevent ESD-induced damage and/or degradation, take customary and statutory ESD precautions when handling this product.

#### Warranty

SENSIRION warrants solely to the original purchaser of this product for a period of 12 months (one year) from the date of delivery that this product shall be of the quality, material and workmanship defined in SENSIRION's published specifications of the product. Within such period, if proven to be defective, SENSIRION shall repair and/or replace this product, in SENSIRION's discretion, free of charge to the Buyer, provided that:

- notice in writing describing the defects shall be given to SENSIRION within fourteen (14) days after their appearance;
- such defects shall be found, to SENSIRION's reasonable satisfaction, to have arisen from SENSIRION's faulty design, material, or workmanship;
- the defective product shall be returned to SENSIRION's factory at the Buyer's expense; and

• the warranty period for any repaired or replaced product shall be limited to the unexpired portion of the original period. This warranty does not apply to any equipment which has not been installed and used within the specifications recommended by SENSIRION for the intended and proper use of the equipment. EXCEPT FOR THE WARRANTIES EXPRESSLY SET FORTH HEREIN, SENSIRION MAKES NO WARRANTIES, EITHER EXPRESS OR IMPLIED, WITH RESPECT TO THE PRODUCT. ANY AND ALL WARRANTIES, INCLUDING WITHOUT LIMITATION, WARRANTIES OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE, ARE EXPRESSLY EXCLUDED AND DECLINED.

SENSIRION is only liable for defects of this product arising under the conditions of operation provided for in the data sheet and proper use of the goods. SENSIRION explicitly disclaims all warranties, express or implied, for any period during which the goods are operated or stored not in accordance with the technical specifications.

SENSIRION does not assume any liability arising out of any application or use of any product or circuit and specifically disclaims any and all liability, including without limitation consequential or incidental damages. All operating parameters, including without limitation recommended parameters, must be validated for each customer's applications by customer's technical experts. Recommended parameters can and do vary in different applications.

SENSIRION reserves the right, without further notice, (i) to change the product specifications and/or the information in this document and (ii) to improve reliability, functions and design of this product.

Copyright © 2021, by SENSIRION. CMOSens® is a trademark of Sensirion. All rights reserved

### **Headquarters and Subsidiaries**

<b>Sensirion AG</b>	Sensirion Inc., USA	Sensirion Korea Co. Ltd.
Laubisruetistr. 50	phone: +1 312 690 5858	phone: +82 31 337 7700~3
CH-8712 Staefa ZH	info-us@sensirion.com	info-kr@sensirion.com
Switzerland	www.sensirion.com	www.sensirion.com/kr
phone: +41 44 306 40 00	Sensirion Japan Co. Ltd.	Sensirion China Co. Ltd.
fax: +41 44 306 40 30	phone: +81 3 3444 4940	phone: +86 755 8252 1501
info@sensirion.com	info-jp@sensirion.com	info-cn@sensirion.com
www.sensirion.com	www.sensirion.com/jp	www.sensirion.com/cn
Sensirion Taiwan Co. Ltd phone: +886 3 5506701 info@sensirion.com www.sensirion.com	To find your local representative, p www.sensirion.com/distributors	lease visit