

Witty Pi 4 Mini:

Realtime Clock and Power Management for Raspberry Pi

User Manual (revision 1.01)



Copyright © 2022 Dun Cat B.V., All rights reserved.

UUGear is a trade name of Dun Cat B.V.



Table of Contents

| 1. | Product Overview1 | | | | |
|----|--|--|---|--|--|
| | 1.1 | Accurate Realtime Clock and ON/OFF Scheduling | 2 | | |
| | 1.2 | Temperature Controlled Device | 2 | | |
| | 1.3 | e-Latching Power Switch | 3 | | |
| | 1.4 | Interface Introduction | 4 | | |
| 2. | Specif | ication / Technical Details | 5 | | |
| 3. | Packa | ge Content | 5 | | |
| 4. | How D | oes Witty Pi Work? | 6 | | |
| 5. | Softwa | are Installation, Updating and Uninstallation | 7 | | |
| | 5.1 | Install Software | 7 | | |
| | 5.2 | Update Software | 7 | | |
| | 5.3 | Uninstall Software | 7 | | |
| 6. | Mounting Witty Pi 4 Mini on Raspberry Pi8 | | | | |
| | | | | | |
| | 6.1 | Mounting Witty Pi 4 Mini on Raspberry Pi Zero | 8 | | |
| | 6.1 6.2 | Mounting Witty Pi 4 Mini on Raspberry Pi Zero Mounting Witty Pi4 Mini on Other Raspberry Pi Models | 8 | | |
| 7. | 6.1 6.2 Softwa | Mounting Witty Pi 4 Mini on Raspberry Pi Zero Mounting Witty Pi4 Mini on Other Raspberry Pi Models are Usage | 8 8 11 | | |
| 7. | 6.1 6.2 Softwa 7.1 | Mounting Witty Pi 4 Mini on Raspberry Pi Zero Mounting Witty Pi4 Mini on Other Raspberry Pi Models are Usage Write system time to RTC | 8 8 11 11 | | |
| 7. | 6.1 6.2 Softwa 7.1 7.2 | Mounting Witty Pi 4 Mini on Raspberry Pi Zero Mounting Witty Pi4 Mini on Other Raspberry Pi Models are Usage Write system time to RTC Write RTC time to system | 8 8 11 11 12 | | |
| 7. | 6.1 6.2 Softwa 7.1 7.2 7.3 | Mounting Witty Pi 4 Mini on Raspberry Pi Zero Mounting Witty Pi4 Mini on Other Raspberry Pi Models are Usage Write system time to RTC Write RTC time to system Synchronize time | 8 11 11 12 12 | | |
| 7. | 6.1 6.2 Softwa 7.1 7.2 7.3 7.4 | Mounting Witty Pi 4 Mini on Raspberry Pi Zero Mounting Witty Pi4 Mini on Other Raspberry Pi Models are Usage Write system time to RTC Write RTC time to system Synchronize time Schedule next shutdown | 8 11 11 12 12 12 | | |
| 7. | 6.1 6.2 Softwa 7.1 7.2 7.3 7.4 7.5 | Mounting Witty Pi 4 Mini on Raspberry Pi Zero Mounting Witty Pi4 Mini on Other Raspberry Pi Models are Usage Write system time to RTC Write RTC time to system Synchronize time Schedule next shutdown Schedule next startup | 8 8 11 12 12 12 12 | | |
| 7. | 6.1 6.2 Softwa 7.1 7.2 7.3 7.4 7.5 7.6 | Mounting Witty Pi 4 Mini on Raspberry Pi Zero Mounting Witty Pi4 Mini on Other Raspberry Pi Models are Usage Write system time to RTC Write RTC time to system Synchronize time Schedule next shutdown Schedule next startup Choose Schedule Script | 8 11 12 12 12 12 12 | | |
| 7. | 6.1 6.2 Softwa 7.1 7.2 7.3 7.4 7.5 7.6 7.7 | Mounting Witty Pi 4 Mini on Raspberry Pi Zero Mounting Witty Pi4 Mini on Other Raspberry Pi Models are Usage Write system time to RTC Write RTC time to system Synchronize time Schedule next shutdown Schedule next shutdown Choose Schedule Script Set low voltage threshold | 8 11 12 12 12 12 12 1 | | |
| 7. | 6.1 6.2 Softwa 7.1 7.2 7.3 7.4 7.5 7.6 7.7 7.8 | Mounting Witty Pi 4 Mini on Raspberry Pi Zero Mounting Witty Pi 4 Mini on Other Raspberry Pi Models are Usage Write system time to RTC Write RTC time to system Synchronize time Schedule next shutdown Schedule next shutdown Choose Schedule Script Set low voltage threshold Set recovery voltage threshold | 8 11 12 12 12 12 12 12 | | |

Copyright © 2022 Dun Cat B.V., All rights reserved.

UUGear is a trade name of Dun Cat B.V.



| | 7.10 | Set below temperature action | 14 |
|-----|-------|--|----|
| | 7.11 | View/change other settings | 14 |
| | 7.12 | Reset Data | 15 |
| | 7.13 | Exit | 16 |
| 8. | Using | UWI (UUGear Web Interface) | 17 |
| 9. | About | Schedule Script | 18 |
| | 9.1 | How does Schedule Script Work? | 18 |
| | 9.2 | Make Your Own Schedule Script | 20 |
| | 9.3 | Using Schedule Script Generator | 22 |
| | 9.4 | Advanced Usage of Schedule Script | 23 |
| 10. | Kno | w More about the Realtime Clock | 24 |
| | 10.1 | Super Capacitor and Time Keeping | 24 |
| | 10.2 | Alarms and Alarm Output | 24 |
| | 10.3 | Temperature Compensation | 24 |
| 11. | Add | itional Interfaces | 26 |
| | 11.1 | The Unpopulated 3-Pin Header (P2) | 26 |
| | 11.2 | The Unpopulated 7-Pin Header on the Top (P3) | 26 |
| | 11.3 | The Unpopulated 2 x 3 Pin Headers (P4) | 28 |
| | 11.4 | The Unpopulated 7-Pin Header in the Middle (P5) | 29 |
| 12. | Inte | grate with Other Programs | 30 |
| 13. | Mig | rating from Witty Pi 3 Mini to Witty Pi 4 Mini | 32 |
| 14. | Witt | y Pi Log Files | 34 |
| 15. | Free | quently Asked Questions (FAQ) | 35 |
| | 15.1 | What I2C address is used by Witty Pi 4 Mini? Can I change it? | 35 |
| | 15.2 | What I ² C Registers are provided by Witty Pi 4 Mini? | 36 |
| | 15.3 | What GPIO Pins Are Used by Witty Pi4? | 43 |
| | 15.4 | Is Witty Pi 4 Mini Compatible with "Other Hardware"? | 44 |

Copyright © 2022 Dun Cat B.V., All rights reserved.



| | 15.5 | Witty Pi 4 Mini does not boot? | 44 |
|-----|------|---|----|
| | 15.6 | Why Raspberry Pi Immediately Turns On after Shutdown? | 47 |
| 16. | Rev | ision History | 48 |

Copyright © 2022 Dun Cat B.V., All rights reserved.

UUGear is a trade name of Dun Cat B.V.



1. Product Overview

Witty Pi is an add-on board that adds realtime clock and power management to your Raspberry Pi. It can define your Raspberry Pi's ON/OFF sequence, and significantly reduce the energy usage. Witty Pi 4 Mini is the fourth generation of Witty Pi and it has these hardware resources onboard:

- Factory calibrated and temperature compensated realtime clock with ±2ppm accuracy.
- Dedicated temperature sensor with 0.125 °C resolution.
- AVR 8-bit microcontroller (MCU) with 8 KB programmable flash.



Witty Pi 4 Mini has very similar design with <u>Witty Pi 4</u>, however **it doesn't come with a DC/DC converter** onboard, and **it uses super capacitor** for RTC time keeping when no power supply is connected. Witty Pi 4 Mini has solder pads on the back, which allow you to solder a DC/DC converter (LDO or switching DC/DC converter) there.



1.1 Accurate Realtime Clock and ON/OFF Scheduling

The realtime clock (RTC) on Witty Pi 4 Mini has been calibrated in the factory and Witty Pi 4 Mini's firmware also makes temperature compensation for the crystal. This makes the RTC very accurate and the actual annual error is limited within ±2ppm (about 1 minute per year). When your Raspberry Pi boots up, the time stored in the RTC will overwrite the system time. As a result, your Raspberry Pi knows the correct time even without accessing the Internet.

You can schedule the startup and/or shutdown of your Raspberry Pi, and make it a time-controlled device. You can even <u>define a schedule script</u> to schedule complicated ON/OFF sequence for your Raspberry Pi.



Scheduling the ON/OFF sequence for Raspberry Pi is the most popular feature of Witty Pi, and it is extremely useful for systems that powered by battery. By only turning on Raspberry Pi when necessary, the battery can work much longer with Witty Pi installed.

1.2 Temperature Controlled Device

The temperature sensor on Witty Pi 4 Mini has 0.125 °C resolution. The temperature data is used for compensating the crystal and make the RTC more accurate.

You can also specific the action (startup or shutdown) when temperature goes above or below the preset threshold. Which means you can also make your Raspberry Pi a temperature-controlled device.





1.3 e-Latching Power Switch

Witty Pi 4 Mini implements an e-Latching power switch, which is very similar to the power switch on your PC/laptop computer. You can gracefully turn on/off your Raspberry Pi with a single tap on the button. The software running in background will execute the shutdown command before the power gets cut, and it avoids the data corruption caused by "hard" shutdown.



UUGear 🋟

1.4 Interface Introduction

Witty Pi 4 Mini supports all Raspberry Pi models that has the 40-pin GPIO header, including A+, B+, 2B, Zero, Zero W, Zero 2 W, 3B, 3B+, 3A+ and 4B. You will need to solder the 40-pin header to Zero/Zero W/Zero 2 W model beforehand, so they can make reliable connection with Witty Pi.

The picture below shows the available interfaces of Witty Pi 4 Mini.



| 0 | PST O | SCK O | MISO O | 1 | C GND | CATHODE |
|------|-------|--------|--------|-------------|--------|---------|
| | O GND | O MOSI | CVE O | - | CLXOUT | INTRPT |
| Swit | ch 4 | | SYS | -UP 0-17 | | |
| 0 | 000 | | 0 0 | 00 | 00 | 0 0 |

- 1. USB type C connector for 5V power input (5V)
- 2. Super capacitor for off-power time keeping
- 3. Unpopulated 7-pin header for extension or integration
- 4. Red LED as power indicator
- 5. On/off switch
- 6. White LED as status indicator
- 7. 2x20 pin stacking header for connecting to Raspberry Pi
- 8. Unpopulated power header with VIN, 5V and GND
- 9. Unpopulated 7-pin header for internal I2C bus and extra signals
- 10. ICSP header for uploading firmware (on the back)



2. Specification / Technical Details

| Dimension | 65mm x 30mm x 4mm |
|--------------------------|---|
| Weight | 9g (net weight without accessories) |
| Microcontroller | ATtiny841 (<u>datasheet</u>) |
| Realtime Clock | PCF85063A (<u>datasheet</u>), calibrated in factory. |
| Temperature Sensor | LM75B (<u>datasheet</u>) |
| MOSFET Switch | AO4620 (<u>datasheet</u>) |
| Super Capacitor | 0.07F |
| Power In | DC 5V (via USB type C connector) or 5V in unpopulated header P2 |
| Output Current | Up to 2.5A for Raspberry Pi and its peripherals |
| Standby Current | ~0.5mA |
| Operating Environment | Temperature -30°C~80°C (-22°F~176°F) Humidity 0~80%RH, no condensing, no corrosive gas |

3. Package Content

Each package of Witty Pi 4 Mini contains:

- Witty Pi 4 Mini board x 1
- M2.5 x 10mm plastic screws x 4
- 4mm plastic spacer x 4
- M2.5 plastic nut x 4



UUGear 🏅

4. How Does Witty Pi Work?

The diagram below shows the basic workflow of how Witty Pi turns on/off your Raspberry Pi.



After you tap the button on Witty Pi, it powers your Raspberry Pi via the GPIO header, and your Raspberry Pi will boot. Witty Pi's software will run automatically after boot, which will send the SYS_UP signal (via GPIO-17) to Witty Pi. Witty Pi's firmware receives the SYS_UP signal and starts to listen to Raspberry Pi's TXD pin (GPIO-14). If you shut down your Raspberry Pi (running shutdown command or choose "Shutdown" in GUI), the TXD pin will go LOW and Witty Pi will cut the power after some delay. If you tap the button again, that equals to shorting GPIO-4 to GND, and Witty Pi's software will run shutdown command for you.

Witty Pi has realtime clock (RTC) onboard and it always knows the time. You can schedule the shutdown and startup of your Raspberry Pi, which are implemented with two alarms. When the alarm is triggered, Witty Pi's firmware will emulate a "button clicking", which will turn on/off your Raspberry Pi accordingly. You can either configure single alarm for shutdown and/or startup, or you can define a simple script to plan a rather complex on/off sequence for your Raspberry Pi.

Witty Pi has Analogue to Digital Converter (ADC) in its microcontroller (MCU), which can measure the input voltage (VIN in unpopulated header P2). If the voltage drops below the preset threshold, Witty Pi's firmware will emulate a "button clicking" to turn off your Raspberry Pi. If the voltage is raised above the preset threshold, Witty Pi's firmware will emulate another "button clicking" to turn on your Raspberry Pi again. This allows you to turn off/off your Raspberry Pi according to input voltage, and it works even without soldering a DC/DC converter to your Witty Pi 4 Mini.

Witty Pi also has temperature sensor onboard. If the temperature rises over the preset threshold, Witty Pi's firmware can emulate a "button clicking" to turn off or turn on your Raspberry Pi. If the temperature drops below the preset threshold, Witty Pi can also turn on/off your Raspberry Pi. You can define the complete logic according to your needs, and turn your Raspberry Pi to a temperature-controlled device.

UUGear 🏅

5. Software Installation, Updating and Uninstallation

5.1 Install Software

To install the software, please run this command to download the installation script:

pi@raspberrypi:~ \$ wget https://www.uugear.com/repo/WittyPi4/install.sh

Then you can run the command below to install the software:

pi@raspberrypi:~ \$ sudo sh install.sh

We use "sudo" here because install.sh needs to register the wittypi service (daemon.sh) to run automatically after boot, which needs root privilege.

The install.sh will also run UWI installation script. If you already have UWI installed before, it will compare the versions and update your UWI when needed.

5.2 Update Software

If there is a newer version of software and you want to install it, in most of the time you just need to repeat the installation process and let it overwrite your current version.

If you prefer, you can also fully uninstall the software (please see below) and then install it again.

5.3 Uninstall Software

To uninstall the software, you need to remove the "wittypi" directory (the one that includes the software files) and remove wittypi service from the auto-run list. Please use this command:

pi@raspberrypi:~ \$ update-rc.d -f wittypi remove

If you also want to uninstall UWI, you need to remove the "uwi" directory and remove uwi service from the auto-run list. Please use this command:





6. Mounting Witty Pi 4 Mini on Raspberry Pi

6.1 Mounting Witty Pi 4 Mini on Raspberry Pi Zero

If you want to use Witty Pi 4 Mini on Raspberry Pi Zero (V1.2, V1.3, W and 2W), you will need to solder the 20x2 pin male header on it first, or you can buy one with the header soldered already.

Remarks: putting the header in place will not be enough, and you have to solder it.



You can simply mount Witty Pi 4 Mini on your Raspberry P Zero's 40-pin header, and it can work just like that. However, if you wish, you can use the plastic screws, spacers and nuts in the package to tightly mount Witty Pi 4 Mini on your Raspberry Pi Zero. Please make sure NOT to put Witty Pi 4 Mini up-side-down, and the 40 pins on Raspberry Pi should connect to the female header via the holes underneath Witty Pi 4 Mini, as shown in figure below.



6.2 Mounting Witty Pi4 Mini on Other Raspberry Pi Models

Other Raspberry Pi models (A+, B+, 2B, 3B, 3B+ and 4B) have the 40 pin header soldered already, so it is possible to directly mount Witty Pi 4 Mini over them. However, because of the existence of



display connector, you will not be able to firmly connect them.



In order to make reliable connection, we suggest to use a <u>stacking pin header</u> (not included in the package).



Those 40 extra-long pins on stacking header should reach the female header via the holes on the back of Witty Pi 4 Mini (as shown in figure above). You can then place a steel ruler (or something similar) between the two rows of pins and push Witty Pi 4 Mini down until it reaches the plastic of the stacking header, as shown in figure below:





After mounting Witty Pi 4 Mini on your Raspberry Pi, and connect the power supply to the USB type C connector on Witty Pi 4 Mini, you can see the white LED blinking, which means it is standing by. Please do not connect power supply to your Raspberry Pi directly, because Witty Pi will power your Raspberry Pi via the GPIO header, and that is how it performs the power management.



Now your Witty Pi 4 Mini is ready to go.

If you want to take off the stacking header from Witty Pi 4 Mini, the proper way is to put your Witty Pi 4 Mini up-side-down, and let the 40 pins contact a flat surface (e.g. desktop), hold the two edges of the board and press down. That way the stacking header will be taken off safely. See the figure below:





7. Software Usage

The main executable (wittyPi.sh) is a bash script, and you can run it like this:

pi@raspberrypi:~/wittypi \$./wittyPi.sh

This interactive script displays the status of the device, and accepts your input to make configuration accordingly.

pi@raspberrypi:~/wittypi \$./wittyPi.sh

```
Witty Pi - Realtime Clock + Power Management for Raspberry Pi
```

 \langle Version 4.00 \rangle by Dun Cat B.V. (UUGear)

```
>>> Current temperature: 35.625° C / 96.125° F
```

```
>>> Your system time is: 2022-05-15 11:14:18 CEST
>>> Your RTC time is: 2022-05-15 11:14:17 CEST
```

>>> Vout=5.00V, Iout=0.51A

```
Now you can:
```

- 1. Write system time to RTC
- 2. Write RTC time to system
- 3. Synchronize with network time
- 4. Schedule next shutdown
- 5. Schedule next startup
- 6. Choose schedule script
- 7. Set low voltage threshold
- 8. Set recovery voltage threshold
- 9. Set over temperature action
- 10. Set below temperature action
- 11. View/change other settings...
- 12. Reset data...
- 13. Exit
- What do you want to do? (1^{13})

There are 13 options in the main menu, and you can input the number and press ENTER to confirm. Every time you press ENTER, the script will re-print the device status so you can see if the change has taken affect.

7.1 Write system time to RTC

This option will copy the time from your Raspberry Pi system to the Realtime Clock on Witty Pi. This



option should be used when you find the Raspberry Pi system time is correct (may be synchronized from the Internet) while the RTC time is not correct.

7.2 Write RTC time to system

This option will copy the time from the Realtime Clock on Witty Pi to your Raspberry Pi system. This option should be used when you find the RTC time is correct while the system time is not correct.

7.3 Synchronize time

If you choose this option, it will check if Internet is accessible, and apply network time to Raspberry Pi system and RTC when possible.

If your Raspberry Pi is not connected to Internet, choosing this option will do nothing.

7.4 Schedule next shutdown

This option allows you to specify when your Raspberry Pi should shutdown automatically.

Please notice the input format should be "DD HH:MM:SS". DD means the day in the month, HH is the hour, MM is the minute and SS is the second. All these should be 2 digits and 24-hour system should be used.

Different than the previous version of Witty Pi, **the "??" wildcard is no longer supported**. This is because the alarms are now implemented by the micro controller, and the MCU does not have enough resource to implement this wildcard. However, you can use schedule script to do what "??" wildcard does. Please refer the <u>Migrating from Witty Pi 3 Mini to Witty Pi 4 Mini</u> chapter.

Schedule script can actually make much more complex schedule. You can find more details in Schedule Script section.

7.5 Schedule next startup

This option allows you to specify when your Raspberry Pi should startup automatically.

Here you will need to input the startup time in the same "DD HH:MM:SS" format, and again the "??" wildcard is not supported here. You can use schedule script to do the same and even better.

7.6 Choose Schedule Script

If you want to define a complex ON/OFF sequence for your Raspberry Pi, you should schedule script.

A schedule script (.wpi file) defines a loop, with all states and their durations inside. After Raspberry Pi is boot, the "runScript.sh" will be run automatically, which will schedule the next shutdown and next startup for you, and hence a complex ON/OFF sequence could be achieved.



After you select the "Choose schedule script" option, it will list all schedule scripts in the "schedules" folder. You can choose one, and then Witty Pi will load and run it.

If you want to confirm what the script is doing, you can check the "schedule.log" file in the "~/wittypi" directory, when your Raspberry Pi is running.

If you want to create your own schedule script, please read the "Making Schedule Script" section.

7.7 Set low voltage threshold

If you connect the VIN pin in P2 to an external voltage source, Witty Pi 4 Mini will monitor that voltage. If that voltage goes below the low voltage threshold, Witty Pi 4 Mini will shut down your Raspberry Pi. Here you can specify the low voltage from 2.0V to 25.0V. If you want to disable the low voltage threshold, just set it to 0.

This functionality can work even without soldering a DC/DC converter to your Witty Pi 4 Mini.

7.8 Set recovery voltage threshold

If you connect the VIN pin in P2 to an external voltage source, Witty Pi 4 Mini will monitor that voltage. If that voltage goes above the recovery voltage threshold, Witty Pi 4 Mini will turn on your Raspberry Pi if it was previously shut down due to too low input voltage. Here you can specify the recovery voltage from 2.0V to 25.0V. If you want to disable the recovery voltage threshold, just set it to 0.

This functionality can work even without soldering a DC/DC converter to your Witty Pi 4 Mini.

Remarks: the low voltage threshold and recovery voltage threshold can be set individually and their combinations will make Witty Pi work differently.

| Low Voltage | Recovery Voltage | Result |
|-------------------------------|---------------------|--|
| Not Set | Not Set | Witty Pi doesn't care about the input voltage changing. |
| Set | Not Set | Witty Pi will shut down your Raspberry Pi if input voltage is too low. It will not turn on Raspberry Pi unless you tap the button, or the scheduled startup comes (given input voltage is higher than low voltage threshold). |
| Set | Set | Witty Pi will shut down your Raspberry Pi if input voltage is too low. Once this happens, Witty Pi will monitor the input voltage during the sleep and will turn on your Raspberry Pi when input voltage gets higher than recovery voltage threshold. |
| Not Set Set V v ti a | | Witty Pi will wake up your Raspberry Pi when input voltage is higher than recovery voltage threshold. Please mind that if input voltage is always higher than recovery voltage threshold, you will not be able to turn off your Raspberry Pi with these settings, because it always turns on Raspberry Pi again just after shutting it down. |



The low voltage threshold and recovery voltage threshold can be set individually and their combinations will make Witty Pi works differently, please see the table below for details.

7.9 Set over temperature action

Here you can specify what to do if temperature exceeds a preset threshold. It does nothing by default, but you can choose to shut down or startup your Raspberry Pi when this event happens.

The action you chose will be triggered when the temperature is higher than the temperature you input. For example, if you input 55°C here, the action will be triggered when actual temperature is 56°C or higher.

Remarks: shutdown can be triggered by temperature only after 2 minutes since Raspberry Pi is on.

7.10 Set below temperature action

Here you can specify what to do if temperature drops under a preset threshold. It does nothing by default, but you can choose to shut down or startup your Raspberry Pi when this event happens.

The action you chose will be triggered when the temperature is lower than the temperature you input. For example, if you input 55°C here, the action will be triggered when actual temperature is 54°C or lower.

Remarks: shutdown can be triggered by temperature only after 2 minutes since Raspberry Pi is on.

7.11 View/change other settings...

Choosing this option will display a sub menu and allows you to set these parameters:

• Default state when powered

It is "OFF" by default, which means your Raspberry Pi will not be turned on when power supply is connected to Witty Pi, and you will need to tap the button on Witty Pi to start it. Here you can set it to 1 (ON) or 0 (OFF).

• Power cut delay after shutdown

Default value is 5.0 seconds, which means Witty Pi will fully cut the power after 5 seconds since Raspberry Pi has been shut down. Here you can input a number between 0.0 to 25.0.

• Pulsing interval during sleep

This parameter will decide how long Witty Pi's micro controller will wake up and drive the white LED and/or the dummy load. By default, this interval is 4 seconds. If you wish the white LED blinks slower, or the dummy load draws current less frequently, you can choose a bigger value. This value is in seconds.

• White LED duration

This parameter will decide how long the white LED should stay on, when Witty Pi blinks it during the sleep. The default value is 100, and you can use bigger value if you wish the white



LED to stay on for longer. Here you can input number from 0 to 255. If you input 0, the white LED will not blink at all.

• Dummy load duration

This parameter will decide how long the dummy load should draw current from the power source.

What is (pulsing) dummy load? It is a trick to keep power bank alive, when Raspberry Pi is off. If you are using power bank to power Witty Pi 4 Mini + Raspberry Pi, after turning off Raspberry Pi and cut the power, Witty Pi 4 Mini only draws about 1mA from the power bank, which is way too small to keep the power bank alive. If the power bank goes to sleep mode, it will not provide any power to Witty Pi 4 Mini and hence your Raspberry Pi will not wake up when scheduled startup is due. Pulsing dummy load is such a trick, that it draws rather big current from the power bank for a short duration and it does so with a fixed interval. That way the power bank might be fooled and think the load is heavy enough, and avoid entering the sleep mode.

The default value of dummy load duration is 0, which means disabled (no dummy load at all). You can set a value between 0 and 255 here. However, **we suggest using smallest value that could keep your power bank alive, usually 10 will do**.

• Vin adjustment

The voltage is measured by the 10-bit ADC in micro controller. Due to the inaccuracy of internal voltage standard and error on divider resistors, the result could have up to 5% error. You can configure this parameter to adjust the result of voltage measurement. The default value is set to 0.20V, and you can input a value between -1.27 and 1.27 here.

• Vout adjustment

You can configure this parameter to adjust the result of output voltage measurement. The default value is set to 0.20V, and you can input a value between -1.27 and 1.27 here.

• lout adjustment

The output current is calculated by measuring the voltage drop on the 0.05 Ohm sampling resistor. You can configure this parameter to adjust the result of output current calculation. The default value is set to 0.00A, and you can input a value between -1.27 and 1.27 here.

7.12 Reset Data...

If you want to erase some data you previously set (scheduled startup time, scheduled shutdown time, currently used schedule script, low voltage threshold, recovery voltage threshold), you can choose this option.

Once you select this option, the software will display a sub menu, which allows you to:

• Clear auto startup time:

The auto-startup time will be erased and Witty Pi will not auto-start your Raspberry Pi.

UUGear 🛟

- Clear auto shutdown time: The auto-shutdown time will be erased and Witty Pi will not auto-shutdown your Raspberry Pi.
- Stop using schedule script: The "schedule.wpi" file will be deleted.
- Clear low voltage threshold: The low voltage threshold will be unset.
- Clear recovery voltage threshold The recovery voltage threshold will be unset.
- Clear over temperature action The over temperature action will be cleared.
- Clear below temperature action The below temperature action will be cleared.
- Perform all actions above:

Clear all scheduled times, remove the "schedule.wpi" file, unset the low voltage and recovery voltage thresholds, clear the over-temperature and below temperature actions. This is the fastest option to clear everything and prevent your Raspberry Pi being shut down by Witty Pi.

7.13 Exit

Selecting this option will exit the software and return to the console.



8. Using UWI (UUGear Web Interface)

UWI is a mini web server that uses very little system resource, while it allows you to monitor and configure your Witty Pi board via any device that can access the network, including mobile phones and tablets.

By default, UWI can be accessed via <u>http://raspberrypi:8000/wittypi4/</u>. If you cannot access it, most probably is because the host name "raspberrypi" is not resolved in your network environment. In such case, please configure your UWI to use actual IP address or accessible host name. You can also **run the "diagnose.sh" script** in "uwi" directory to do so automatically.

pi@raspberrypi:~/uwi \$./diagnose.sh

In UWI, your Witty Pi 4 Mini device is presented like this:

| < | ini | |
|---------------------|---|-----------|
| R V | emperature: 31.5°C / 88.7°F Pi Time: 2022-06-30 18:55:26 CEST TC Time: 2022-06-30 18:49:47 CEST Yout=4.83V, Iout=0.36A | • |
| RPi Time ► RTC Time | RPi Time ◀ RTC Time Syr | nchronize |
| Next Shute | lown: not set | Set |
| Next Sta | artup: not set | Set |
| Schedule S | cript: (not in use) | Set |
| Low Vol | Itage: disabled | Set |
| | | |

Here you can monitor and control your Witty Pi 4 Mini device like using a website.



9. About Schedule Script

Besides manually schedule the next shutdown/startup time, you can also use a schedule script to plan the ON/OFF sequence for your Raspberry Pi. A schedule script is a text file with .wpi file extension. Witty Pi's software will load and execute it automatically after Raspberry Pi is boot up.

9.1 How does Schedule Script Work?

A schedule script defines a loop, and it put a serial of ON/OFF states into it. The duration of each state is also specified. At the end of ON state, there should be a scheduled shutdown, while at the end of OFF state, there should be a scheduled. All states in the schedule script will be executed in sequence and repeatedly, until the END time of the loop is reached.



Every time your Raspberry Pi wakes up, it has a chance to run the runScript.sh file, which loads the schedule script ("schedule.wpi" file) and run it. If the current time doesn't reach the END time defined in the schedule script, the next shutdown and next startup will be scheduled automatically. When your Raspberry Pi is wakened at scheduled startup time, it will repeat this process and schedule the next shutdown and startup. Although a schedule script only defines a few ON/OFF states, they could become many ON/OFF states in reality.





Please keep in mind that, running the same schedule script at different moment may get different result, as the "runScript.sh" will search and find the proper state according to current time.



When the "runScript.sh" is executed, if the current time is located at an "OFF" state instead, it will take the next "ON" state as the current state, because it knows Raspberry Pi is currently ON.



This "shifting ON state" behavior confuses some users, because the actual scheduled shutdown/startup times are different than what they expected. In such case you can adjust the BEGIN time of the schedule script, and you will see the scheduled shutdown/startup times will move accordingly.



9.2 Make Your Own Schedule Script

A schedule script is actually a text file, and you can use any text editor to create and edit it.

Below is a very simple schedule script and it will keep your Raspberry Pi on for 5 minutes in every 20 minutes.

| # Turn on Raspberry Pi for 5 minutes, in every 20 minutes | | | | | |
|---|---------------------|---------------------------------|--|--|--|
| BEGIN 2021-08-01 00:00:00 | | | | | |
| END | 2025-07-31 23:59:59 | | | | |
| ON | M5 | # keep ON state for 5 minutes | | | |
| OFF | M15 | # keep OFF state for 15 minutes | | | |

Like many other scripting languages, Witty Pi's schedule script also uses "#" to make single line comment.

The first two lines define the time range for executing the script. Please make sure to use the correct time format (YYYY-mm-DD HH:MM:SS). You can use one or more white characters (space or tab) between BEGIN/END and the time string.

The rest of the script defines the states in the loop. It could be "ON" or "OFF", and you should define at least one "ON" and one "OFF" states in the loop. The ON and OFF states are used in pair.

You should also specify the duration of each state. You can do so by putting one or more parameters after ON/OFF text, separated by space or tab. Each parameter starts with a capital letter and follows by a number, where the capital letter is the unit of time:

- D = Days (D2 means 2 days)
- H = Hours (H3 means 3 hours)
- M = Minutes (M15 means 15 minutes)
- S = Seconds (S30 means 30 seconds)

For example, if you wish to define an ON state for one and a half hours, you can write:

ON H1 M30

When the script engine executes this line, it will schedule a shutdown at the end of the ON state.

If you wish to define an OFF state for two days, you can write:

OFF D2

When this line gets executed, a startup will be scheduled at the end of the OFF state.



Sometimes you may want to skip certain scheduling of shutdown/startup, and let your own program to do the job. This can be achieved by using the WAIT syntax. For example:

ON M15 WAIT

This will keep your Raspberry Pi ON and no shutdown will be scheduled after 15 minutes, because there is a WAIT at the end of the line. The parameter M15 is here only to make sure the next OFF state can be calculated correctly and next shutdown can be scheduled properly.

Once you use WAIT in the ON state, you (or your program) are responsible for the shutdown of your Raspberry Pi. If you use WAIT in the OFF state, you will need to turn on your Raspberry Pi (manually or via external electronic switch).

After installing the software, there are some schedule scripts in the "schedules" directory, and they all have comments inside to explain themselves. You can take them as example to learn how to create the Witty Pi schedule script.



9.3 Using Schedule Script Generator

You can also use our web application to create your schedule script. Just simply open this URL in your web browser:

https://www.uugear.com/app/wittypi-scriptgen/

This web application allows you to visually create the schedule script, and it immediately generate the final code on the right.

You can also click the "Run Now" button to preview how the schedule script will work. Alternatively, you can click the "Run at..." button and specify the moment to run the script.





9.4 Advanced Usage of Schedule Script

Besides choosing the schedule script from wittyPi.sh, you can also use schedule script without the help from wittyPi.sh. Just copy the schedule script file to "~/wittypi/schedule.wpi" and then run "./runScript.sh" in the "~/wittypi" directory, the script will start to work. This allows you to use schedule script as an interface, to integrate other tools with Witty Pi together. For example, you can create your own tool to visually create a schedule script, or remotely generate the schedule script via a web interface.





10. Know More about the Realtime Clock

Witty Pi 4 Mini uses PCF85063A realtime clock for time keeping. The realtime clock has been calibrated in factory, and can reach **±2ppm accuracy**. The workflow to calibrate the realtime clock can be found in chapter 8.2.3.3 in <u>PCF85064A's datasheet</u>.

10.1 Super Capacitor and Time Keeping

Witty Pi 4 Mini uses a 0.07F super capacitor for off-power time keeping. Which means the realtime clock can still keep the correct time after you disconnect power supply from Witty Pi 4 Mini.

This super capacitor only powers the realtime clock chip (PCF85063), which only draws \sim 0.22µA current. The super capacitor can keep time for about 17 hours without external power supply connected.

If your Witty Pi 4 Mini always have power supply connected, you don't need to worry about losing time. The realtime clock will not lose the correct time when Raspberry Pi is off, because the realtime clock is still powered by the connected power supply. The super capacitor is helpful when you need to move the device to another site, or your device experiences power failure.

10.2 Alarms and Alarm Output

Witty Pi needs two alarms (one for scheduled startup and one for scheduled shutdown), but PCF85063A has only one. That's why we implemented two alarms in the firmware instead. This also brings an advantage that both alarms now can be accurate to seconds.

The ALM/ALARM in unpopulated header P3 is connected to the alarm output of realtime clock. This pin will stay in 3.3V level and will be pulled to 0V when an alarm occurs. This signal is for integration purpose, so other systems can know whether Witty Pi 4 Mini has triggered an alarm.

Because the realtime clock itself only has one alarm, Witty Pi 4 Mini's firmware always copies the nearly overdue alarm data to the realtime clock, so both alarms can trigger the ALM/ALARM signal.

10.3 Temperature Compensation

In order to get even better accuracy, Witty Pi 4 Mini's firmware also makes temperature compensation for the crystal it uses. The temperature compensation bases on the fact that the actual frequency of the crystal changes according to the temperature. The frequency-temperature curve has been measured and the data are used for such compensation.

UUGear 🋟



The orange curve is the actual measured temperature – frequency error curve. Witty Pi 4 Mini's firmware uses the green four-segment line to approximate the actual curve for temperature compensation.



11. Additional Interfaces

11.1 The Unpopulated 3-Pin Header (P2)

On the left edge of Witty Pi 4 Mini board, there is an unpopulated 3-pin header, and you can solder a male or female connector here.



You can either input 5V between the "5V" and GND pins, or input a non-5V voltage between the "VIN" and "GND" pins.

The VIN pin in this header is to input a voltage to power Witty Pi (with DC/DC converter soldered on the back) or to let Witty Pi to monitor the voltage (to shut down and startup the device according to voltage).

11.2 The Unpopulated 7-Pin Header on the Top (P3)

On the upper edge of Witty Pi 4 Mini board, there is an unpopulated 7-pin header, and you can solder a male or female connector here.



(Front View)

(Back View)

This header breaks out some useful signals and is very helpful for extension and integration. The pins from left to right (at top view) are VOUT, 3V3, LED, ALARM, SWITCH, CATHODE and GND.

VOUT

This pin is actually connected to the +5V pin in Raspberry Pi's GPIO header, which is also the output voltage of Witty Pi 4 Mini board. You can also know whether your Raspberry Pi is in ON state by measuring this voltage.

Please notice that your **Raspberry Pi is powered by the voltage between VOUT and CATHODE**. The GND in this header is the ground for Witty Pi 4 Mini, but not the ground for Raspberry Pi.



If there is another device need to get powered (by 5V) with Raspberry Pi together, you can connect it to this VOUT and CATHODE pins.

3V3

It is 3.3V voltage on Witty Pi 4 Mini board that powers the micro controller, RTC and temperature sensor. It has nothing to do with the 3.3V pin in Raspberry Pi's GPIO header.

LED

It is connected to the anode of the white LED. You can use this pin to connect your own LED, but don't forget to put a 1K resistor in serial to limit the current.



ALM / ALARM

It is the interrupt signal that generated by the RTC alarm. It is in 3.3V level and has HIGH state (3.3V) by default. If any alarm occurs (scheduled startup or shutdown), it goes to LOW state (0V), and this state will be cleared once Witty Pi 4 Mini's software detects and processes it.

SW / SWITCH

It is the signal line that connects to the switch (button) on Witty Pi 4 Mini. It is also directly connected to GPIO-4 in Raspberry Pi's GPIO header. If you want to connect your own (2-lead) switch, you may wire the two leads to SWITCH/GPIO-4 and GND pins.



Alternatively, if you wish to trigger Witty Pi 4 Mini with external signal, you can use a N-channel MOSFET to achieve this:





The signal should be a positive pulse. Processing a pulse will be equal to taping the switch once, so it will turn on your Raspberry Pi when it is off, or turn off your Raspberry Pi when it is on.

CATH / CATHOD

It is the cathode (ground) for Raspberry Pi. There is a 0.05 Ohm sampling resistor between CATHOD and GND, to measure the actual output current.



If you measure the voltage between cathode and ground as V_k , you can calculate the actual current with this formula:

$$I_{out} = V_k / 0.05 = 20 * V_k$$

GND

It is the ground of Witty Pi 4 Mini board, and it directly connects to the GND wire of power supply.

11.3 The Unpopulated 2 x 3 Pin Headers (P4)

This is the In-Circuit Serial Programming (ICSP) header for uploading the firmware to the micro controller. You can find the same ICSP header on many Arduino boards. The details about how to use this header can be found in <u>this tutorial</u>.



11.4 The Unpopulated 7-Pin Header in the Middle (P5)

In the middle of Witty Pi 4 Mini board, there is another unpopulated 7-pin header, where you can also solder a male or female connector.



(Front View)



(Back View)

This header breaks out the internal I2C bus and also some useful signals.

CLKOUT

This is the 32768Hz clock output signal from the RTC. This signal can be used to calibrate the RTC.

INTRPT

This is the interrupt signal from the RTC, and it is actually the same as the ALM/ALARM pin in another unpopulated header P3. It goes LOW when alarm is occurred.

3V3

It is 3.3V voltage on Witty Pi 4 Mini board that powers the micro controller, RTC and temperature sensor. It has nothing to do with the 3.3V pin in Raspberry Pi's GPIO header. It is the same as 3V3 in P3.

OTEMP

This pin is at HIGH (3.3V) level by default. It goes to LOW (~0V) level when the current temperature exceeds the preset over-temperature threshold. It will go back to HIGH level when the current temperature drops under the below-temperature threshold.

I-SCL and I-SDA

These are the SCL and SDA for internal I2C bus. The RTC and temperature sensor are directly connected to this internal I2C bus.

GND

It is the ground of Witty Pi 4 Mini board, and it directly connects to the GND wire of power supply.



12. Integrate with Other Programs

Witty Pi's software is written in BASH, and it is very easy to modify and integrate with other programs. The daemon.sh script is registered to be executed after boot, and this registration was done by the installation script (using update-rc.d command). In the daemon.sh script, it will run beforeScript.sh before executing the schedule script (schedule.wpi), and run afterStartup.sh file before waiting for GPIO-4 falling, and also run the beforeShutdown.sh before actually shutdown Raspberry Pi.



If you want to run your own program before executing the schedule script (e.g. your program will generate a new schedule script file), you can put your program command(s) in **beforeScript.sh**.

If you want to run your own program after executing the schedule script (e.g. your program will use the scheduled date time for next shutdown), you can put your program command(s) in afterStartup.sh.

If you want to run your own program before shutting down your Raspberry Pi (e.g. your program will send out an email before shutdown), you can put your program command(s) in **beforeShutdown.sh**.

Please keep in mind the daemon.sh script will be executed by root user, which means it may not



have required path information for frequently used commands. As a result, you will need to use full path for all commands in beforeScript.sh, afterStartup.sh and beforeShutdown.sh. Below is an example:

```
while [ "$(/usr/bin/hostname -I)" = "" ]; do
   /usr/bin/sleep 1
done
/usr/bin/wget "https://www.uugear.com/" >/home/pi/wittypi/wget.log 2>&1
```

This code snippet waits for network and then query the webpage from UUGear's website. Please notice the full path for commands and files.

hostname \rightarrow /usr/bin/hostname sleep \rightarrow /usr/bin/sleep wget \rightarrow /usr/bin/wget wget.log \rightarrow /home/pi/wget.log

If you are not sure about the full path of a command, you can use whereis command to find out.

pi@raspberrypi:~ \$ whereis sleep

sleep: /usr/bin/sleep /usr/share/man/man1/sleep.1.gz /usr/share/man/man3 sleep 3.gz

All commands you put in beforeScript.sh, afterStartup.sh or beforeShutdown.sh will be executed in sequence. If one of the commands takes rather long time, the commands after it will be postponed accordingly.

If you don't want a command to block other commands, you can run it in the background by appending "&" at the end of that command, like this:

```
/usr/bin/wget "https://www.uugear.com/" >/home/pi/wittypi/wget.log 2>&1 &
```



13. Migrating from Witty Pi 3 Mini to Witty Pi 4 Mini

If you have been using Witty Pi 3 Mini before, migrating to Witty Pi 4 Mini will be quite easy to you. Witty Pi 4 Mini has the same shape factor like Witty Pi 3 Mini, and the locations of button and connectors are the same. **They are physically exchangeable**.

In Witty Pi 3 Mini, you cannot specify the "seconds" in scheduled shutdown time, and that was due to the limitation from RTC hardware. In Witty Pi 4 Mini, the alarms for startup and shutdown are implemented by the firmware, and **you can specify the "seconds" in both scheduled times**.

The "??" wildcards are no longer supported in Witty Pi 4 Mini. This is because implementing "??" wildcards need more resources than what MCU has. However, you can still use schedule script to achieve the same result. The table below shows how to use schedule to replace the "??" wildcards.

| Wildcard Use Case | Explanation | Equivalent with Schedule Script |
|--|---|--|
| Startup: ?? 09:45:00 Shutdown: ?? 22:30:00 | Turn on at 9:45, and turn off at 22:30 every day. | BEGIN2022-05-10 09:45:00END2025-07-31 23:59:59ONH12 M45OFFH11 M15 |
| Startup: <mark>?? 09:45:00</mark> Shutdown: no plan | Turn on at 9:45 every day, and do not schedule the shutdown. | BEGIN 2022-05-10 09:45:00 END 2025-07-31 23:59:59 ON M5 WAIT OFF H23 M55 |
| Startup: no plan Shutdown: ?? 22:30:00 | Turn off at 22:30 every day, and do not schedule the startup. | BEGIN 2022-05-10 22:25:00 END 2025-07-31 23:59:59 ON M5 OFF H23 M55 WAIT |
| Startup: ?? ??:40:00 Shutdown: ?? ??:55:00 | Turn on at 40 minutes and turn off at 55 minutes every hour. | BEGIN2022-05-10 00:40:00END2025-07-31 23:59:59ONM15OFFM45 |
| Startup: ?? ??:40:00 Shutdown: no plan | Turn on at 40 minutes every hour, and do not schedule the shutdown. | BEGIN 2022-05-10 00:40:00 END 2025-07-31 23:59:59 ON M5 WAIT OFF M55 |
| Startup: no plan Shutdown: ?? ??:30:00 | Turn off at 30 minutes every hour, and do not schedule the startup. | BEGIN 2022-05-10 00:25:00 END 2025-07-31 23:59:59 ON M5 OFF M55 WAIT |



If your system has integrated Witty Pi 3 Mini's software and you have called the functions in utilities.sh file. You will need to **compare the two versions of utilities.sh files** and make sure all functions you use are still there. We try not to change the function names, but there are some functions get added/removed.

If your system also directly accesses Witty Pi 3 Mini via I2C interface, you will need to **change the I2C address and register indexes accordingly**. Witty Pi 3 Mini exposes two I2C devices to the bus (address 0x68 and 0x69), while Witty Pi 4 Mini exposes only one I2C devices to the bus (address 0x08). In Witty Pi 4 Mini, the I2C registers in RTC and temperature sensor are mapped to virtual I2C registers in single device. Please refer the "<u>What I²C Registers are provided by Witty Pi 4 Mini</u>" section for more information.



14. Witty Pi Log Files

In the directory that you install your Witty Pi software, you can find two log files: **schedule.log** and **wittyPi.log**. If you need our help for solving a problem, please kindly put the log files in email attachment too. This will help us to help you better.

The "schedule.log" file contains the history of schedule script executions. In this log file you can see how the next shutdown and startup were scheduled. If you saw unexpected schedule script behavior, this log should be the first file to check.

The "wittyPi.log" file records the history of all Witty Pi activities. If you think your Witty Pi doesn't behave correctly, this log file might provide more information for troubleshooting.

The time-stamp in the log file is always the system time, instead of the RTC time. During the booting, the first log written by Witty Pi's software is "Witty Pi daemon (vX.XX) is started.", but its time-stamp is not shown. You will see the correct time after the RTC time has been written to the system. For example:



The correct time-stamp firstly appears in the line with text "Done :-)", so you know this startup happened at 14:05.

When the booting is done, the last log written by Witty Pi software is "Pending for incoming shutdown command...".

Again, if you need our help for solving a problem, please kindly put the log files in email attachment too. In the majority of cases, they will help us a lot to help you better.



15. Frequently Asked Questions (FAQ)

15.1 What I2C address is used by Witty Pi 4 Mini? Can I change it?

Witty Pi 4 Mini implements its own I2C master to communicate with realtime clock and temperature sensor, and only exposes one I2C slave device to Raspberry Pi, which has an I²C address: **0x08**. This address is configurable and you can change it if you want.

If you have Witty Pi 4 Mini connected to Raspberry Pi and run "i2cdetect –y 1" command in the console, you will see this:



If you want to change the I²C address used by Witty Pi 4 Mini, you can change the value of I²C register at position #16. For example, if you want to change the I²C address to 0x35, you can run:

pi@raspberrypi:~ \$ i2cset -y 1 8 16 0x35

After that you also need to modify the "utilities.sh" file (in wittyPi directory). Find the I2C_MC_ADDRESS variable and change its value from 0x08 to 0x35.

In order to access Witty Pi 4 Mini in UWI, you also need to modify the "uwi/wittypi4/api.sh" file. Find "if ["\$value" == "08"]; then" and replace the "08" to "35".

The final step is to shut down your Raspberry Pi, fully disconnect the power supply of your Witty Pi 4 Mini, and then reconnect the power supply. Then the MCU will start working with new address.



15.2 What I²C Registers are provided by Witty Pi 4 Mini?

The micro controller on Witty Pi 4 Mini works as an I²C slave and Raspberry Pi can read/write its registers via I²C interface. Witty Pi's software configures Witty Pi 4 Mini by setting the I²C register accordingly.

The micro controller also implements an I²C master to access the realtime clock and temperature sensor via internal I²C bus. The I²C registers in realtime clock and temperature sensor are all mapped as virtual I²C registers in Witty Pi 4 Mini's I²C slave device, so Raspberry Pi can also access them (not always necessary though).



The temperature sensor contains 4 I²C registers and they are mapped to virtual registers #50~#53. The realtime clock contains 18 I²C registers and they are mapped to virtual registers #54~#71. In Raspberry Pi's view, Witty Pi 4 Mini provides 3 kinds of I²C registers:

- Read-only I²C registers
- Normal I²C registers
- Virtual I²C registers

The table below shows the registers provided by Witty Pi 4 Mini. As you can see, some of them are read-only (cannot be changed, or can only be updated by the firmware itself):



| Index | Description | Range | Default | Accessible |
|-------|--|--------|---------|------------|
| 0 | Firmware ID | | 0x36 | Read-only |
| 1 | Integer part for input voltage | 0~255 | 0 | Read-only |
| 2 | Decimal part (multiple 100 times) for input voltage | 0~99 | 0 | Read-only |
| 3 | Integer part for output voltage | 0~255 | 0 | Read-only |
| 4 | Decimal part (multiple 100 times) for output voltage | 0~99 | 0 | Read-only |
| 5 | Integer part for output current | 0~255 | 0 | Read-only |
| 6 | Decimal part (multiple 100 times) for output current | 0~99 | 0 | Read-only |
| 7 | Power mode: Power via LDO regulator = 1 Input 5V via USB Type C = 0 | 1 or 0 | 1 | Read-only |
| 8 | A flag indicates whether the previous shutdown was due to low voltage: • Yes = 1 • No = 0 | 1 or 0 | 0 | Read-only |
| 9 | A flag indicates whether ALARM1 (startup) has been triggered. Yes = 1 No = 0 | 1 or 0 | 0 | Read-only |
| 10 | A flag indicates whether ALARM2 (shutdown) has been triggered. • Yes = 1 • No = 0 | 1 or 0 | 0 | Read-only |

UUGear 🋟

| 11 | The reason code for latest action. | 0~8 | 0 | Read-only |
|----|--|--------|------|--------------|
| | • 0 = N/A | | | |
| | • 1 = ALARM1 | | | |
| | • 2 = ALARM2 | | | |
| | • 3 = Button is clicked | | | |
| | 4 = Input voltage too low | | | |
| | 5 = Input voltage is restored | | | |
| | • 6 = over temperature | | | |
| | • 7 = below temperature | | | |
| | • 8 = ALARM1 delayed | | | |
| 12 | The firmware revision | 1~255 | 1 | Read-only |
| 13 | Reserved for future usage #1 | 0~255 | 0 | Read-only |
| 14 | Reserved for future usage #2 | 0~255 | 0 | Read-only |
| 15 | Reserved for future usage #3 | 0~255 | 0 | Read-only |
| 16 | I2C slave address: default=0x08 | 0x08 | 0x08 | Read & Write |
| | | ~0x77 | | |
| 17 | State when power connected: | 1 or 0 | 0 | Read & Write |
| | Default On = 1 | | | |
| | • Default Off = 0 | | | |
| 18 | Pulse interval in seconds, when Raspberry Pi is off. This parameter affects the white LED blinking and dummy load. | 0~255 | 4 | Read & Write |
| 19 | Low voltage threshold (multiple 10 times, 255=disabled) | 0~255 | 255 | Read & Write |
| 20 | LED lights up duration. 0 if white LED should not blink. The bigger value, the longer time to light up | 0~255 | 100 | Read & Write |



| | the white LED | | | |
|----|---|-----------|-----|--------------|
| 21 | The delay (multiple 10) before power cut: default=50 (5 seconds) | 0~255 | 50 | Read & Write |
| 22 | Recovery voltage threshold (multiple 10, 255=disabled) | 0~255 | 255 | Read & Write |
| 23 | Dummy load duration. 0 if dummy load is off. The bigger value, the longer time for dummy load to draw current | 0~255 | 0 | Read & Write |
| 24 | Adjustment for measured input voltage (multiple 100) | -127~127 | 20 | Read &Write |
| 25 | Adjustment for measured output voltage (multiple 100) | -127 ~127 | 20 | Read & Write |
| 26 | Adjustment for measured output current (multiple 100) | -127 ~127 | 0 | Read & Write |
| 27 | Second of ALARM1 (startup), with BCD format | 0~59 | 0 | Read & Write |
| 28 | Minute of ALARM1 (startup), with BCD format | 0~59 | 0 | Read & Write |
| 29 | Hour of ALARM1 (startup), with BCD format | 0~23 | 0 | Read & Write |
| 30 | Day of ALARM1 (startup), with BCD format | 1~31 | 1 | Read & Write |
| 31 | Weekday of ALARM1 (startup), with BCD format | 0~6 | 0 | Read & Write |
| 32 | Second of ALARM2 (shutdown), with BCD format | 0~59 | 0 | Read & Write |
| 33 | Minute of ALARM2 (shutdown), with BCD format | 0~59 | 0 | Read & Write |
| 34 | Hour of ALARM2 (shutdown), with BCD format | 0~23 | 0 | Read & Write |
| 35 | Day of ALARM2 (shutdown), with BCD format | 1~31 | 1 | Read & Write |
| 36 | Weekday of ALARM2 (shutdown), with BCD format | 0~6 | 0 | Read & Write |



| 37 | Standard value for RTC offset | -127~127 | 0 | Read & Write |
|----|--|----------|----|--------------|
| 38 | Turn on/off temperature compensation. ON = 1 OFF = 0 | 0 or 1 | 1 | Read & Write |
| 39 | A flag that indicates ALARM1 (startup) is triggered and not processed. | 0 or 1 | 0 | Read & Write |
| 40 | A flag that indicates ALARM2 (shutdown) is triggered and not processed. | 0 or 1 | 0 | Read & Write |
| 41 | Set 1 to ignore I2C_POWER_MODE for low voltage shutdown and recovery. | 0 or 1 | 0 | Read & Write |
| 42 | Set 1 to ignore I2C_LV_SHUTDOWN for low voltage shutdown and recovery. | 0 or 1 | 0 | Read & Write |
| 43 | Below-temperature action: 0 = do nothing 1 = shutdown 2 = startup | 0~2 | 0 | Read & Write |
| 44 | Below-temperature threshold in °C | -30~80 | 75 | Read & Write |
| 45 | Over-temperature action: 0 = do nothing 1 = shutdown 2 = startup | 0~2 | 0 | Read & Write |
| 46 | Over-temperature threshold in °C | -30~80 | 80 | Read & Write |
| 47 | Reserved for future usage #4 | 0~255 | 0 | Read & Write |
| 48 | Reserved for future usage #5 | 0~255 | 0 | Read & Write |
| 49 | Reserved for future usage #6 | 0~255 | 0 | Read & Write |



| 50 | LM75B: temperature register | (2 bytes) | ? | Read-only | |
|----|--|-----------|----------------|--------------|--|
| 51 | LM75B: configuration register | 0~255 | 0 | Read & Write | |
| 52 | LM75B: hysteresis temperature register | (2 bytes) | 75 | Read & Write | |
| 53 | LM75B: overtemperature register | (2 bytes) | 80 | Read & Write | |
| 54 | PCF85063: Control_1 register | 0~255 | 0 | Read & Write | |
| 55 | PCF85063: Control_2 register | 0~255 | 0 Read & Write | | |
| 56 | PCF85063: Offset register | 0~255 | 0 | Read & Write | |
| 57 | PCF85063: RAM_byte register | 0~255 | 0 | Read & Write | |
| 58 | PCF85063: Seconds register | 0~59 | 0 | Read & Write | |
| 59 | PCF85063: Minutes register | 0~59 | 0 | Read & Write | |
| 60 | PCF85063: Hours register | 0~23 | 0 | Read & Write | |
| 61 | PCF85063: Days register | 1~31 | 1 | Read & Write | |
| 62 | PCF85063: Weekdays register | 0~6 | 0 | Read & Write | |
| 63 | PCF85063: Months register | 1~12 | 1 | Read & Write | |
| 64 | PCF85063: Years register | 0~99 | 0 | Read & Write | |
| 65 | PCF85063: Second_alarm register | 0~59 | 0 | Read & Write | |
| 66 | PCF85063: Minute_alarm register | 0~59 | 0 | Read & Write | |
| 67 | PCF85063: Hour_alarm register | 0~23 | 0 | Read & Write | |
| 68 | PCF85063: Day_alarm register | 1~31 | 1 | Read & Write | |
| 69 | PCF85063: Weekday_alarm register | 0~6 | 0 | Read & Write | |
| 70 | PCF85063: Timer_value register | 0~255 | 0 | Read & Write | |



| 71PCF85063: Timer_mode register0~2550Read & Write |
|---|
|---|

Below is an example to read the register with index 7, to know the current power mode (0x00 means input 5V via the USB Type C connector):



And below is an example to write the register with index 18, to set the pulsing interval to 1 second:

```
pi@raspberrypi:~ $ i2cset -y 1 0x08 18 1
```

Remarks: although the register with index 16 is writable, **changing the I2C address is more than writing an I²C register**. You will need to modify the software accordingly, and reconnect the power supply to make it work. You can find more details in the "<u>What I2C address is used by Witty Pi 4 Mini?</u> <u>Can I change it?</u>" section.

UUGear 🏅

15.3 What GPIO Pins Are Used by Witty Pi4?

The GPIO pins used by Witty Pi 4 Mini are marked with green color in the table below.

| GPIO (BCM) | Name | Physical | | Name | GPIO (BCM) |
|---------------|---------|----------|----|---------|---------------|
| | 3.3V | 1 | 2 | 5V | |
| 2 | SDA 1 | 3 | 4 | 5V | |
| 3 | SCL 1 | 5 | 6 | GND | |
| 4 | GPIO 7 | 7 | 8 | TXD | 14 |
| | GND | 9 | 10 | RXD | 15 |
| 17 | GPIO 0 | 11 | 12 | GPIO 1 | 18 |
| 27 | GPIO 2 | 13 | 14 | GND | |
| 22 | GPIO 3 | 15 | 16 | GPIO 4 | 23 |
| | 3.3V | 17 | 18 | GPIO 5 | 24 |
| 10 | MOSI | 19 | 20 | GND | |
| 9 | MISO | 21 | 22 | GPIO 6 | 25 |
| 11 | SCLK | 23 | 24 | CE0 | 8 |
| | GND | 25 | 26 | CE1 | 7 |
| 0 | SDA 0 | 27 | 28 | SCL 0 | 1 |
| 5 | GPIO 21 | 29 | 30 | GND | |
| 6 | GPIO 22 | 31 | 32 | GPIO 26 | 12 |
| 13 | GPIO 23 | 33 | 34 | GND | |
| 19 | GPIO 24 | 35 | 36 | GPIO 27 | 16 |
| 26 | GPIO 25 | 37 | 38 | GPIO 28 | 20 |
| | GND | 39 | 40 | GPIO 29 | 21 |

As you can see, Witty Pi 4 Mini uses GPIO-4, GPIO-17, GPIO-2(SDA 1) and GPIO-3(SCL 1).

Witty Pi 4 Mini doesn't actually use the TXD pin, but it will monitor its voltage. The TXD pin is supposed to be HIGH when the system is on, and should go LOW after system has been shut down. If you connect some other devices that also use the TXD pin, please make sure they don't change this default behavior, otherwise Witty Pi 4 Mini doesn't know when the system is off, and cannot fully cut the power.



GPIO-2 and GPIO-3 are for I²C communication between Raspberry Pi and the MCU (ATtiny841). I²C devices are identified by I²C address, and they can share the I²C pins as long as they have different I²C addresses.

15.4 Is Witty Pi 4 Mini Compatible with "Other Hardware"?

We have got a lot of emails asking a question like this, with the "Other Hardware" replaced by different kinds of hardware.

Please understand that we might not have the hardware you refer, and even if we have, it is difficult for us to make tests on all those hardware with Witty Pi 4 Mini. Fortunately, it is not that difficult to figure out the answer by yourself. Basically, you just need to consider the I²C address and GPIO pins used by the "Other Hardware".

If the "Other Hardware" also uses 0x08 I²C address, you will need to change the I²C address used by Witty Pi's micro controller, and change the software accordingly (details <u>here</u>).

If the "Other Hardware" doesn't use any GPIO pin that used by Witty Pi, then it should be compatible with Witty Pi.

If you have no idea which I²C address (if applicable) or GPIO pins are used by the "Other Hardware", please contact its developer, as they certainly know their hardware and can provide you accurate information about it.

15.5 Witty Pi 4 Mini does not boot?

Some customers meet the situation that Witty Pi 4 Mini only boot Raspberry Pi for a few seconds, and then shutdown Raspberry Pi or cut the power directly.

Remarks: you may need to disconnect Witty Pi 4 Mini from your Raspberry Pi, and power on Raspberry Pi only for troubleshooting.

Before making further troubleshooting, please first check these interfaces are properly configured:

- I2C interface should be enabled
- Serial Port should be enabled
- 1-Wire interface should be disabled if you don't need it, or you need to assign a GPIO pin other than GPIO-4 to it.

If your Raspbian (Raspberry Pi OS) has GUI installed, you can review/configure these interfaces via Raspberry Pi Configuration:



| | Raspberry | / Pi Configuratio | n 🗸 🗸 |
|-----------------|------------|----------------------------|-----------------------------|
| System | Interfaces | Performance | Localisation |
| Camera: | | • Enable | Disable |
| SSH: | | • Enable | O Disable |
| VNC: | | • Enable | Disable |
| SPI: | | Enable | Disable |
| 120: | | Enable | O Disable |
| Serial Port: | | • Enable | Disable |
| Serial Console: | | Enable | Disable |
| 1-Wire: | | O Enable | Disable |
| Remote GPIO: | | • Enable | O Disable |
| | | | Cancel OK |

Also, you can check all GPIO pin states with the command below. You need to run it in the directory that has software installed (usually "wittypi").

pi@raspberrypi:~/wittypi \$ bash -c '. gpio-util.sh; gpio readall'

The good GPIO states are shown below (please mind those highlighted in green). If you see something different, then it might be the culprit that causes the problem.

| + | | + | + | ++ | B PI | lus | | | | ++ | |
|-----|-----|---------|------|-------|-------------------------|-------------|---|------|---------|-----|-----|
| BCM | wPi | Name | Mode | I V I | Physi | ical | ۷ | Mode | Name | wPi | BCM |
| 1 1 | | 3.3v | | | 1 | 2 | | | 5v | | |
| 2 | 8 | SDA.1 | ALT0 | 1 | 3 | 4 | | | 57 | | |
| 3 | 9 | SCL.1 | ALT0 | 1 | 5 | 6 | | | 0v | | |
| 4 | 7 | GPIO.7 | IN | 1 | 7 | 8 | 1 | ALT0 | TxD | 15 | 14 |
| 1 | | 0v | | | 9 | 10 | 1 | ALT0 | RxD | 16 | 15 |
| 17 | 0 | GPIO. 0 | I IN | 0 | 11 | 12 | 0 | IN | GPIO.1 | 1 | 18 |
| 27 | 2 | GPIO. 2 | I IN | 0 | 13 | 14 | | | 0v | | |
| 22 | 3 | GPIO. 3 | I IN | 0 | 15 | 16 | 0 | IN | GPIO. 4 | 4 | 23 |
| 1 1 | | 3.3v | | | 17 | 18 | 0 | IN | GPIO.5 | 5 | 24 |
| 10 | 12 | MOSI | I IN | 0 | 19 | 20 | | | 0v | | |
| 9 | 13 | MISO | I IN | 0 | 21 | 22 | 0 | IN | GPIO.6 | 6 | 25 |
| 11 | 14 | SCLK | I IN | 0 | 23 | 24 | 1 | IN | CEØ | 10 | 8 |
| | | 0v | | | 25 | 26 | 1 | IN | CE1 | 11 | 7 |
| 0 | 30 | SDA.0 | I IN | 1 | 27 | 28 | 1 | IN | SCL.0 | 31 | 1 |
| 5 | 21 | GPI0.21 | I IN | 1 | 29 | 30 | | | 0v | | |
| 6 | 22 | GPI0.22 | I IN | 1 | 31 | 32 | 0 | IN | GPI0.26 | 26 | 12 |
| 13 | 23 | GPI0.23 | I IN | 0 | 33 | 34 | | | 0v | | |
| 19 | 24 | GPI0.24 | I IN | 0 | 35 | 36 | 0 | IN | GPI0.27 | 27 | 16 |
| 26 | 25 | GPI0.25 | IN | 0 | 37 | 38 | 0 | IN | GPI0.28 | 28 | 20 |
| | l | 0v | l | | 39 | 40 | 1 | IN | GPI0.29 | 29 | 21 |
| + | wPi | Name | Mode | V | ⊦++ Physi ⊦B P∣ | ical lus | V | Mode | Name | | BCM |

pi@raspberrypi ~/wittyPi \$ gpio readall

There are some possible reasons that can cause this kind of problem:



1. You are using NOOBS

NOOBS is not always causing this kind of problem, but the chance does exist. If you installed multiple operating systems into your Pi, the chance that NOOBS causes this problem will increase. If possible, please try not to use NOOBS. If you already use NOOBS and still try to make it work, you may set a big <u>power cut delay</u> value (e.g. 25 seconds). If it doesn't help, you will need to install the OS without using NOOBS.

2. 1-Wire interface is enabled on GPIO-4, which conflicts with Witty Pi

If you have 1-Wire interface enabled, by default it will use GPIO-4. Because Witty Pi uses GPIO-4 pin to receive shutdown command, this will bring confliction and Witty Pi will shut down your Raspberry Pi after every boot. You won't even have chance to login the system.

In order avoid this problem, 1-Wire interface should be disabled, or be assigned to a different GPIO pin before installation of Witty Pi's software. If the problem already happens, you need to take out the micro SD card from Raspberry Pi and access its file system via an SD card reader.

You need to edit the config.txt file in the "boot" volume to change the GPIO pin used by 1-Wire interface, or you can disable 1-Wire interface if you don't need it for now. You need to find something like "dtoverlay=w1-gpio" in the file.

If you want 1-Wire to use GPIO-18, just replace "dtoverlay=w1-gpio" with:

dtoverlay=w1-gpio,gpiopin=18

If you want to disable 1-Wire interface, just comment it out:

#dtoverlay=w1-gpio

Save the file and eject your micro SD card, and put it back to your Raspberry Pi. Now your Raspberry Pi should be able to boot normally.

3. Serial Port is not properly configured

The serial port (UART0) should be enabled, and it should be on GPIO-14 and GPIO-15 (BCM naming). The TXD pin in serial port will be monitored by Witty Pi and it goes to LOW when the system has been shut down. If the serial port is not properly configured, the TXD pin doesn't have proper default state and Witty Pi may mistakenly think the system is off and then cut the power after some delay.



4. GPIO-4 pin doesn't reach a stable status in given time

After the system is on, GPIO-4 pin should be in input mode and gets internally pulled up. However, during the startup the GPIO-4 pin could be unstable. In the **daemon.sh** script, the GPIO-4 listener will be started once the pin state hasn't changed for 5 seconds. Once the GPIO-4 listener is started, any action that pulls down GPIO-4 will be regarded as a shutdown command. So if GPIO-4 pin doesn't really get stable after that given 5 seconds, Witty Pi will take it as a shutdown command, **lights up the white LED** and then shutdown the system.

There are many factors that might cause the GPIO pin unstable, and **the most common one is the power supply**. If your power supply is not strong enough, during the booting its voltage may drop from time to time, which may also make the GPIO pin voltage drop, and trigger Witty Pi's software to shut down your Raspberry Pi.

If it is the case, you can try to delay the starting of GPIO-4 listener, and in the majority of cases it will help. You can modify the "daemon.sh" script, in line 94:

while [\$counter - It 5]; do

Try to change the number 5 to 25. The bigger number you use, the later the GPIO-4 listener will be started.

This modification may workaround the problem. If it doesn't, it means your GPIO-4 is really pulled down (by software or hardware), and you can confirm that by measuring the voltage on GPIO-4 with a multimeter. By default, the GPIO-4 should be internally pulled up. If it gets pulled down, try to find out who does this and don't let it do this again.

15.6 Why Raspberry Pi Immediately Turns On after Shutdown?

When ALARM1 (startup) occurs, Witty Pi's firmware will check Raspberry Pi's status. If Raspberry Pi is off, Witty Pi will turn it on; If Raspberry Pi is still powered, Witty Pi's firmware will cache this startup request and will turn on Raspberry Pi just after it gets power off.

This scenario may happen when your Raspberry Pi's TXD pin does not go LOW after system has been shut down. The reason could be some other hardware strongly pulls up TXD pin, or the system crashed during shutdown. When ALARM1 (startup) occurs, your Raspberry Pi is still powered because the turning off process is still not finished.

When this happens, you can find this message in the wittyPi.log file:

System starts up because of the scheduled startup got delayed. Maybe the scheduled startup was due when Pi was running, or Pi had been shut down but TXD stayed HIGH to prevent the power cut.

This will not be a problem as long as the TXD pin can eventually go LOW after shutdown and the device can continue the ON/OFF sequence.



16. Revision History

| Revision | Date | Description |
|----------|------------|--|
| 1.00 | 2022.07.01 | Initial revision |
| 1.01 | 2022.07.20 | Add description about super capacitor. |
| | | |
| | | |
| | | |
| | | |
| | | |
| | | |